

SONY VAIO > Batteria DURACELL per BPS13 (10,8/11,1V) > marchio 2POWER

€64,60 (incluso 22 % I.V.A.)



SONY

VAIO

compatibile



stesse dimensioni!
stessi parametri elettrici



2-POWER®

ALTA QUALITÀ'

0,02% di fake contro il 2% delle normali compatibili



À
À

CERCA



il **CODICE** sulla tua batteria!
è l'**UNICO** che individua al
100% il tuo modello.

Model: BATEFL50L9C72

ATTENTO AL VOLTAGGIO

batterie da 10,8/11,1V **NON FUNZIONANO** su pc da 14,4/14,8V e viceversa!

NB: le immagini sono puramente indicative di forma e dimensioni dell'oggetto. Fanno fede le specifiche riportate nell'inserzione.

â-° Compatibile con le seguenti batterie:

Â

VGP-BPS13
VGP-BPS13-B
VGP-BPS13-Q
VGP-BPS13-S
VGP-BPS13A-B
VGP-BPS13A-Q
VGP-BPS13A-S
VGP-BPS13AB
VGP-BPS13AQ
VGP-BPS13AS
VGP-BPS13B-B
VGP-BPS13B-Q
VGP-BPS13B-S
VGP-BPS13BB
VGP-BPS13BQ
VGP-BPS13BS
VGP-BPS13Q
VGP-BPS13S
VGP-BPL13
VGP-BPL21
VGP-BPS21
VGP-BPS21-S
VGP-BPS21A
VGP-BPS21A-B
VGP-BPS21B
VGP-BSP13-S

Â


Â

Â

Suggerimento  CTRL + F
per cercare il tuo modello di portatile

 **ATTENTO**

il codice del pc da solo
NON E' SUFFICIENTE
a stabilire la compatibilità



â-° Compatibile con i seguenti pc portatili:

Â

VGN-AW110J-H
VGN-AW11M-H
VGN-AW11S-B
VGN-AW11XU-Q
VGN-AW11Z-B
VGN-AW160J-Q
VGN-AW170C
VGN-AW180Y-Q
VGN-AW19
VGN-AW19-Q
VGN-AW21M-H
VGN-AW21MH
VGN-AW21S-B
VGN-AW21SB
VGN-AW21VY-Q
VGN-AW21XY-Q
VGN-AW21XYQ
VGN-AW21Z-B
VGN-AW21ZB
VGN-AW220J-H
VGN-AW230J-H
VGN-AW235J-B
VGN-AW270Y-Q
VGN-AW27GY-QE1
VGN-AW290JFQ
VGN-AW310J-H
VGN-AW31M
VGN-AW31M-H
VGN-AW31MH
VGN-AW31S-B
VGN-AW31XY-O
VGN-AW31XY-Q
VGN-AW31ZJ
VGN-AW31ZJ-B
VGN-AW31ZS-B
VGN-AW35GJ-H
VGN-AW35GJH
VGN-AW37GY-Q
VGN-AW37GYQ
VGN-AW390JAH
VGN-AW390JCH
VGN-AW41JF
VGN-AW41JF-H
VGN-AW41MF
VGN-AW41MF-H
VGN-AW41XH
VGN-AW41XH-Q
VGN-AW41ZF
VGN-AW41ZF-B

VGN-AW47GH-Q
VGN-AW47GHQ
VGN-AW4MRF-H
VGN-AW4XRH-Q
VGN-AW4ZRF-B
VGN-AW50DB
VGN-AW50DB-H
VGN-AW51JGB
VGN-AW52JGB
VGN-AW53FB
VGN-AW70B-Q
VGN-AW71JB
VGN-AW72JB
VGN-AW73FB
VGN-AW80NS
VGN-AW80S
VGN-AW80US
VGN-AW81DS
VGN-AW81JS
VGN-AW81YS
VGN-AW82DS
VGN-AW82JS
VGN-AW82YS
VGN-AW83FS
VGN-AW83GS
VGN-AW83HS
VGN-AW90NS
VGN-AW90S
VGN-AW90US
VGN-AW91CDS
VGN-AW91CJS
VGN-AW91CYS
VGN-AW91DS
VGN-AW91JS
VGN-AW91YS
VGN-AW92CDS
VGN-AW92CJS
VGN-AW92CYS
VGN-AW92DS
VGN-AW92JS
VGN-AW92YS
VGN-AW93FS
VGN-AW93GS
VGN-AW93HS
VGN-AW93ZFS
VGN-AW93ZGS
VGN-AW93ZHS
VGN-BZ1
VGN-BZ11EN
VGN-BZ11M-N
VGN-BZ11MN
VGN-BZ11VN
VGN-BZ11XN

VGN-BZ12EN
VGN-BZ12V-N
VGN-BZ12VN
VGN-BZ12XN
VGN-BZ13VN
VGN-BZ13XN
VGN-BZ153N
VGN-BZ153N-E1
VGN-BZ15GN
VGN-BZ16GN
VGN-BZ2
VGN-BZ21VN
VGN-BZ21XN
VGN-BZ26M
VGN-BZ26V
VGN-BZ26X
VGN-BZ31VT
VGN-BZ31XT
VGN-BZ540N-B
VGN-BZ560CTO
VGN-BZ560N22
VGN-BZ560N24
VGN-BZ560N26
VGN-BZ560N30
VGN-BZ560N32
VGN-BZ560N34
VGN-BZ563P23
VGN-BZ563P29
VGN-BZ563P30
VGN-BZ569P26
VGN-BZ569P36
VGN-BZ569P38
VGN-BZ569P40
VGN-BZ569P44
VGN-BZ569P45
VGN-BZ569P46
VGN-BZ569P47
VGN-CS1
VGN-CS11S-P
VGN-CS11S-Q
VGN-CS11S-T
VGN-CS11S-W
VGN-CS11Z-R
VGN-CS11Z-T
VGN-CS13H-P
VGN-CS13H-Q
VGN-CS13H-R
VGN-CS13H-W
VGN-CS16T-P
VGN-CS16T-Q
VGN-CS16T-R
VGN-CS16T-T
VGN-CS16T-W

VGN-CS16Z
VGN-CS170F-P
VGN-CS170F-Q
VGN-CS170F-R
VGN-CS17H-Q
VGN-CS17H-W
VGN-CS19-P
VGN-CS19-Q
VGN-CS19-R
VGN-CS19-W
VGN-CS190JTP
VGN-CS190JTQ
VGN-CS190JTR
VGN-CS190JTT
VGN-CS190JTW
VGN-CS2
VGN-CS204J-W
VGN-CS215J-Q
VGN-CS215J-R
VGN-CS21S
VGN-CS21S-P
VGN-CS21S-R
VGN-CS21S-T
VGN-CS21S-V
VGN-CS21S-W
VGN-CS21SP
VGN-CS21SR
VGN-CS21SV
VGN-CS21SVEE9
VGN-CS21Z-Q
VGN-CS220DP
VGN-CS220DQ
VGN-CS220DR
VGN-CS220DT
VGN-CS220DW
VGN-CS230J-P
VGN-CS230J-W
VGN-CS23H-S
VGN-CS23T-Q
VGN-CS23T-W
VGN-CS25H
VGN-CS25H-C
VGN-CS25H-P
VGN-CS25H-Q
VGN-CS25H-R
VGN-CS25H-W
VGN-CS260DQ
VGN-CS260DW
VGN-CS26GW
VGN-CS26T-C
VGN-CS26T-P
VGN-CS26T-Q
VGN-CS26T-R

VGN-CS26T-T
VGN-CS26T-V
VGN-CS26T-W
VGN-CS27
VGN-CS270T-P
VGN-CS270T-Q
VGN-CS270T-R
VGN-CS27C
VGN-CS27P
VGN-CS27R
VGN-CS27W
VGN-CS28
VGN-CS28-Q
VGN-CS280J-Q
VGN-CS290JEC
VGN-CS290JEP
VGN-CS290JEQ
VGN-CS290JER
VGN-CS290JEW
VGN-CS2CN1
VGN-CS3
VGN-CS310J-P
VGN-CS310J-Q
VGN-CS310J-R
VGN-CS310J-W
VGN-CS31GN-B
VGN-CS31S-P
VGN-CS31S-Q
VGN-CS31S-R
VGN-CS31S-T
VGN-CS31S-V
VGN-CS31S-W
VGN-CS31Z-Q
VGN-CS320J-Q
VGN-CS320J-R
VGN-CS325J-P
VGN-CS325J-Q
VGN-CS325J-R
VGN-CS325J-W
VGN-CS32GH-B
VGN-CS32SH-B
VGN-CS33G-W
VGN-CS33H
VGN-CS33H-B
VGN-CS33H-Z
VGN-CS33M-Q
VGN-CS33S-W
VGN-CS34GH-B
VGN-CS35GNB
VGN-CS36GJ-C
VGN-CS36GJ-I
VGN-CS36GJ-J
VGN-CS36GJ-P

VGN-CS36GJ-Q
VGN-CS36GJ-R
VGN-CS36GJ-T
VGN-CS36GJ-U
VGN-CS36GJ-W
VGN-CS36GJC
VGN-CS36GJJ
VGN-CS36GJR
VGN-CS36H
VGN-CS36H-C
VGN-CS36H-P
VGN-CS36H-Q
VGN-CS36H-R
VGN-CS36H-W
VGN-CS36MJ-J
VGN-CS36SJ-P
VGN-CS36TJ-C
VGN-CS36TJ-J
VGN-CS36TJ-P
VGN-CS36TJ-Q
VGN-CS36TJ-R
VGN-CS36TJ-T
VGN-CS36TJ-U
VGN-CS36TJ-V
VGN-CS36TJ-W
VGN-CS385J-Q
VGN-CS385J-R
VGN-CS38GD-B
VGN-CS39
VGN-CS39-J
VGN-CS39-U
VGN-CS390JDV
VGN-CS3AGH-P
VGN-CS50B
VGN-CS50B-W
VGN-CS51B
VGN-CS51B-W
VGN-CS52JB
VGN-CS52JB-W
VGN-CS60B
VGN-CS60B-P
VGN-CS60B-Q
VGN-CS60B-R
VGN-CS61B
VGN-CS61B-P
VGN-CS61B-Q
VGN-CS61B-R
VGN-CS62JB
VGN-CS62JB-P
VGN-CS62JB-Q
VGN-CS62JB-R
VGN-CS71B
VGN-CS71B-W

VGN-CS72JB
VGN-CS72JB-W
VGN-CS90HS
VGN-CS90NS
VGN-CS90S
VGN-CS91HS
VGN-CS91NS
VGN-CS91S
VGN-CS92
VGN-CS92DS
VGN-CS92JS
VGN-CS92XS
VGN-FW11
VGN-FW11E
VGN-FW11ER
VGN-FW11J
VGN-FW11L
VGN-FW11LR
VGN-FW11M
VGN-FW11MR
VGN-FW11S
VGN-FW11SR
VGN-FW11ZRU
VGN-FW11ZU
VGN-FW130EW
VGN-FW130NW
VGN-FW139E-H
VGN-FW139EH
VGN-FW139NW
VGN-FW140EH
VGN-FW140EW
VGN-FW140NW
VGN-FW145E-W
VGN-FW145EW
VGN-FW150EW
VGN-FW15T
VGN-FW160EH
VGN-FW17
VGN-FW17-B
VGN-FW170JH
VGN-FW17T-H
VGN-FW17W
VGN-FW180EH
VGN-FW19
VGN-FW19-B
VGN-FW190EBH
VGN-FW190EDH
VGN-FW198UH
VGN-FW21E
VGN-FW21ER
VGN-FW21I
VGN-FW21J
VGN-FW21L

VGN-FW21M
VGN-FW21MR
VGN-FW21SR
VGN-FW21Z
VGN-FW21ZR
VGN-FW235J
VGN-FW260F-E
VGN-FW260FE
VGN-FW27-B
VGN-FW27-W
VGN-FW270J-W
VGN-FW280F-Y
VGN-FW280FY
VGN-FW29-B
VGN-FW290JRB
VGN-FW290JTB
VGN-FW290JTH
VGN-FW290JTW
VGN-FW290JVH
VGN-FW3
VGN-FW30B
VGN-FW31E
VGN-FW31J
VGN-FW31M
VGN-FW31MEE9
VGN-FW31ZJ
VGN-FW32J
VGN-FW340DW
VGN-FW340J-B
VGN-FW340J-H
VGN-FW350DH
VGN-FW350J-B
VGN-FW350J-H
VGN-FW351J-H
VGN-FW355J-H
VGN-FW35F
VGN-FW35F-B
VGN-FW35F-W
VGN-FW36TJ-B
VGN-FW370J-H
VGN-FW373DW
VGN-FW378J-B
VGN-FW37J
VGN-FW37J-B
VGN-FW390JFB
VGN-FW390YFB
VGN-FW390YLH
VGN-FW398Y-H
VGN-FW4
VGN-FW41E-H
VGN-FW41E-W
VGN-FW41EH
VGN-FW41EHEE9

VGN-FW41EWFR
VGN-FW41J
VGN-FW41J-H
VGN-FW41M
VGN-FW41M-H
VGN-FW41MH
VGN-FW41ZJ
VGN-FW41ZJ-H
VGN-FW41ZJFR
VGN-FW41ZJH
VGN-FW43G-W
VGN-FW43GB
VGN-FW43GW
VGN-FW44MR
VGN-FW450J-B
VGN-FW455J-B
VGN-FW455J-H
VGN-FW45GJ-B
VGN-FW45GJB
VGN-FW45MJ-B
VGN-FW45TJ-B
VGN-FW460J-B
VGN-FW460J-H
VGN-FW460J-T
VGN-FW465J-B
VGN-FW46GJ-B
VGN-FW46GJ-BE1
VGN-FW46GJB
VGN-FW46M
VGN-FW46S
VGN-FW46SJ-B
VGN-FW46Z
VGN-FW47GY-H
VGN-FW47GYH
VGN-FW485J-H
VGN-FW48E-H
VGN-FW5
VGN-FW50B
VGN-FW510F-H
VGN-FW51B
VGN-FW51B-W
VGN-FW51JF-H
VGN-FW51JFH
VGN-FW51MF
VGN-FW51MF-H
VGN-FW51ZF
VGN-FW51ZF-H
VGN-FW52JB
VGN-FW53GF-B
VGN-FW53GF-W
VGN-FW53GFB
VGN-FW53GFW
VGN-FW54E

VGN-FW54FB
VGN-FW54J
VGN-FW54M
VGN-FW54MR
VGN-FW54S
VGN-FW55GF-B
VGN-FW55GFB
VGN-FW56002B
VGN-FW56003B
VGN-FW56004B
VGN-FW56E
VGN-FW56GF-B
VGN-FW56GFB
VGN-FW56J
VGN-FW56M
VGN-FW56SR
VGN-FW56Z
VGN-FW56ZR
VGN-FW57GH-H
VGN-FW57GHH
VGN-FW5ERF-H
VGN-FW5JTF-H
VGN-FW5MTF-H
VGN-FW5ZRF-H
VGN-FW5ZTF-H
VGN-FW70DB
VGN-FW71DB
VGN-FW71DB-W
VGN-FW72JGB
VGN-FW73JGB
VGN-FW74FB
VGN-FW81HS
VGN-FW81NS
VGN-FW81S
VGN-FW82DS
VGN-FW82JS
VGN-FW82XS
VGN-FW83DS
VGN-FW83JS
VGN-FW83XS
VGN-FW90HS
VGN-FW90NS
VGN-FW90S
VGN-FW91NS
VGN-FW91S
VGN-FW92DS
VGN-FW92JS
VGN-FW93DS
VGN-FW93JS
VGN-FW93XS
VGN-FW94FS
VGN-FW94GS
VGN-FW94HS

VGN-NS110E
VGN-NS110E-S
VGN-NS11M-S
VGN-NS11S
VGN-NS11S-S
VGN-NS11Z
VGN-NS11Z-S
VGN-NS12M-W
VGN-NS140E-S
VGN-NS15G-S
VGN-NS15H-S
VGN-NS160E-S
VGN-NS190J-S
VGN-NS190J-W
VGN-NS20E-P
VGN-NS20E-S
VGN-NS20J-S
VGN-NS20M-S
VGN-NS20S-S
VGN-NS20Z-S
VGN-NS215N-S
VGN-NS21E-S
VGN-NS21M
VGN-NS21M-P
VGN-NS21M-S
VGN-NS21M-W
VGN-NS21MW
VGN-NS21S
VGN-NS21S-S
VGN-NS21S-W
VGN-NS21X-S
VGN-NS21Z-S
VGN-NS225J-S
VGN-NS230DP
VGN-NS230DW
VGN-NS230E
VGN-NS230E-L
VGN-NS230E-P
VGN-NS230E-S
VGN-NS230E-W
VGN-NS235J
VGN-NS235J-L
VGN-NS235J-P
VGN-NS235J-S
VGN-NS235J-W
VGN-NS240DP
VGN-NS240DS
VGN-NS240DW
VGN-NS255DS
VGN-NS25G-E1
VGN-NS25G-P
VGN-NS25G-S
VGN-NS25GP

VGN-NS290J-L
VGN-NS290J-S
VGN-NS290J-W
VGN-NS295J-S
VGN-NS30
VGN-NS305D-S
VGN-NS30E-P
VGN-NS30E-S
VGN-NS30E-W
VGN-NS30Z-S
VGN-NS315D-S
VGN-NS31EH-S
VGN-NS31EHS
VGN-NS31M-P
VGN-NS31M-S
VGN-NS31M-W
VGN-NS31MW
VGN-NS31MWFR
VGN-NS31MWG4
VGN-NS31S-S
VGN-NS328J-L
VGN-NS328J-W
VGN-NS36E
VGN-NS38E-S
VGN-NS38M-P
VGN-NS38M-W
VGN-NS38MPG4
VGN-NS38MWG4
VGN-NS50B-L
VGN-NS50B-W
VGN-NS51B
VGN-NS51B-L
VGN-NS51B-P
VGN-NS51B-W
VGN-NS52JB
VGN-NS52JB-L
VGN-NS52JB-P
VGN-NS52JB-W
VGN-NS70B
VGN-NS70B-W
VGN-NS71B
VGN-NS71B-W
VGN-NS72JB
VGN-NS72JB-W
VGN-NS90HS
VGN-NS92JS
VGN-NS92XS SONY
VAIO VGN-NW
VGN-NW11
VGN-NW11S
VGN-NW11S-S
VGN-NW11S-T
VGN-NW11Z-S

VGN-NW11Z-T
VGN-NW120J-S
VGN-NW120J-W
VGN-NW12Z
VGN-NW12Z-S
VGN-NW12Z-T
VGN-NW130J-S
VGN-NW130J-T
VGN-NW130J-W
VGN-NW13GH-T
VGN-NW150J-S
VGN-NW150J-T
VGN-NW15G-T
VGN-NW15GS
VGN-NW15GT
VGN-NW15GW
VGN-NW160J-S
VGN-NW17GJ-S
VGN-NW17GJS
VGN-NW180J-S
VGN-NW20EF-P
VGN-NW20EF-S
VGN-NW20EF-W
VGN-NW20SF-P
VGN-NW20SF-S
VGN-NW20ZF-S
VGN-NW215T
VGN-NW215T-S
VGN-NW21EF
VGN-NW21EF-S
VGN-NW21JF
VGN-NW21JF-S
VGN-NW21MF
VGN-NW21MF-P
VGN-NW21MF-S
VGN-NW21MF-W
VGN-NW21SF-S
VGN-NW21SF-T
VGN-NW21ZF
VGN-NW21ZF-S
VGN-NW21ZF-T
VGN-NW230T
VGN-NW23GF-P
VGN-NW23GFP
VGN-NW240F
VGN-NW240F-P
VGN-NW240F-S
VGN-NW24EG
VGN-NW24JG
VGN-NW24MG
VGN-NW24MR
VGN-NW24S
VGN-NW25GF-B

VGN-NW25GF-P
VGN-NW25GF-S
VGN-NW25GF-T
VGN-NW25GF-W
VGN-NW25GFB
VGN-NW25GFP
VGN-NW25GFS
VGN-NW25GFT
VGN-NW25GFW
VGN-NW26003B
VGN-NW26E
VGN-NW26EG
VGN-NW26JG
VGN-NW26M
VGN-NW26MRG
VGN-NW270F-S
VGN-NW270T
VGN-NW270T-B
VGN-NW275F
VGN-NW29GF-B
VGN-NW29GFB
VGN-NW2ERE-S
VGN-NW2ETF-S
VGN-NW2MRE-P
VGN-NW2MRE-S
VGN-NW2MTF-S
VGN-NW2SRF-S
VGN-NW2STF-T
VGN-NW2ZRF-N
VGN-NW31EF
VGN-NW31EF-S
VGN-NW31EF-W
VGN-NW31JF
VGN-NW31JF-S
VGN-NW320F-B
VGN-NW320F-TC
VGN-NW35E
VGN-NW35E-B
VGN-NW35E-P
VGN-NW35E-W
VGN-NW380F-S
VGN-NW380F-T
VGN-NW50JB
VGN-NW51FB
VGN-NW51FB-N
VGN-NW51FB-W
VGN-NW70JB
VGN-NW71FB
VGN-NW71FB-N
VGN-NW71FB-W
VGN-NW91FS
VGN-NW91GS
VGN-NW91VS

VGN-SR11M
VGN-SR11M-R
VGN-SR11MR
VGN-SR12G-B
VGN-SR12G-P
VGN-SR12G-S
VGN-SR13
VGN-SR13-B
VGN-SR130E-B
VGN-SR130EB
VGN-SR130EP
VGN-SR130ES
VGN-SR130NB
VGN-SR13GN-B
VGN-SR13GN-P
VGN-SR13GN-S
VGN-SR140E-S
VGN-SR140EB
VGN-SR140EP
VGN-SR140ES
VGN-SR140NS
VGN-SR150FN
VGN-SR16
VGN-SR16-P
VGN-SR16-S
VGN-SR165E-B
VGN-SR165E-P
VGN-SR165E-S
VGN-SR165EB
VGN-SR165EP
VGN-SR165ES
VGN-SR165NB
VGN-SR175N-B
VGN-SR175NB
VGN-SR18-J
VGN-SR18-Q
VGN-SR190EBJ
VGN-SR190EBQ
VGN-SR190F
VGN-SR19VN
VGN-SR19VRN
VGN-SR19XN
VGN-SR210J-H
VGN-SR21M
VGN-SR21M-S
VGN-SR220J-B
VGN-SR220J-H
VGN-SR23H-B
VGN-SR240J-B
VGN-SR240N-B
VGN-SR250J-H
VGN-SR25G-B
VGN-SR25G-P

VGN-SR25G-S
VGN-SR25M-B
VGN-SR25S-B
VGN-SR25T-P
VGN-SR25T-S
VGN-SR26-B
VGN-SR26-P
VGN-SR26-S
VGN-SR26GN-B
VGN-SR26MN-B
VGN-SR27TN-B
VGN-SR28-B
VGN-SR28-J
VGN-SR28-Q
VGN-SR290JTH
VGN-SR290JTJ
VGN-SR290JTQ
VGN-SR290JVB-C
VGN-SR290JVH-C
VGN-SR290NTB
VGN-SR29NV-S
VGN-SR29VN-S
VGN-SR29XN-S
VGN-SR3
VGN-SR31M-S
VGN-SR33H
VGN-SR33H-B
VGN-SR33H-P
VGN-SR33H-S
VGN-SR35G-B
VGN-SR35G-E1
VGN-SR35G-P
VGN-SR35G-S
VGN-SR35M-B
VGN-SR35T-B
VGN-SR35T-P
VGN-SR35T-S
VGN-SR36GNS
VGN-SR36MN-B
VGN-SR36MN-P
VGN-SR37M
VGN-SR37TN-B
VGN-SR38
VGN-SR38-B
VGN-SR38-J
VGN-SR38-Q
VGN-SR390NAB
VGN-SR390NAH
VGN-SR390YAB
VGN-SR399PBB
VGN-SR399PCB
VGN-SR39D
VGN-SR39D-J

VGN-SR39D-Q
VGN-SR39VN-S
VGN-SR39XN-S
VGN-SR3CW-B
VGN-SR3S1
VGN-SR4
VGN-SR410J-B
VGN-SR410J-H
VGN-SR41M-P
VGN-SR41M-R
VGN-SR41M-S
VGN-SR41M-W
VGN-SR41VN-H
VGN-SR420J-B
VGN-SR420J-H
VGN-SR43G-B
VGN-SR43G-N
VGN-SR43G-P
VGN-SR43G-W
VGN-SR43S-B
VGN-SR43S-P
VGN-SR45G-B
VGN-SR45G-N
VGN-SR45G-P
VGN-SR45H
VGN-SR45H-B
VGN-SR45H-N
VGN-SR45H-P
VGN-SR45M-B
VGN-SR45M-P
VGN-SR45T-B
VGN-SR45T-P
VGN-SR45T-W
VGN-SR46GD
VGN-SR46GD-B
VGN-SR46GD-P
VGN-SR46GDB
VGN-SR46GDP
VGN-SR46MD-B
VGN-SR46SD-B
VGN-SR46SD-P
VGN-SR46TD-B
VGN-SR46Z
VGN-SR48J
VGN-SR48J-B
VGN-SR48J-J
VGN-SR490JCN
VGN-SR49D
VGN-SR49D-J
VGN-SR49D-Q
VGN-SR49VN-H
VGN-SR49XN-H
VGN-SR5

VGN-SR51B-P
VGN-SR51B-S
VGN-SR51MF-P
VGN-SR51MF-S
VGN-SR51MF-W
VGN-SR51RF-P
VGN-SR51RF-S
VGN-SR51RF-W
VGN-SR530T-F
VGN-SR530TF
VGN-SR53GF-B
VGN-SR53GF-N
VGN-SR53GF-P
VGN-SR53GF-W
VGN-SR53GFB
VGN-SR53GFW
VGN-SR53SF-B
VGN-SR53SF-P
VGN-SR55GF-B
VGN-SR55GF-N
VGN-SR55GF-P
VGN-SR55MF-B
VGN-SR55TF-B
VGN-SR56004H
VGN-SR56GG-B
VGN-SR56GG-S
VGN-SR56GGB
VGN-SR56GGS
VGN-SR56MG-B
VGN-SR56SG-B
VGN-SR56SG-P
VGN-SR56XN
VGN-SR57S
VGN-SR57V
VGN-SR57X
VGN-SR59TG-H
VGN-SR59VG
VGN-SR59VG-H
VGN-SR59XG
VGN-SR59XG-H
VGN-SR70B
VGN-SR70B-S
VGN-SR72B
VGN-SR72B-P
VGN-SR72B-S
VGN-SR73JB
VGN-SR73JB-S
VGN-SR74FB
VGN-SR74FB-S
VGN-SR90FS
VGN-SR90NS
VGN-SR90S
VGN-SR90US

VGN-SR91NS
VGN-SR91PS
VGN-SR91S
VGN-SR91US
VGN-SR92NS
VGN-SR92PS
VGN-SR92S
VGN-SR92US
VGN-SR93DS
VGN-SR93JS
VGN-SR93PS
VGN-SR93YS
VGN-SR94FS
VGN-SR94GS
VGN-SR94VS
VPC-B119GJ
VPC-B119GJ-B
VPC-B11A7E
VPC-B11AGJ
VPC-B11AV
VPC-B11AVJ
VPC-B11V9E
VPC-B11V9E-B
VPC-B11X9E
VPC-B11X9E-B
VPC-CW1
VPC-CW120A-L
VPC-CW120AL
VPC-CW12EN-BU
VPC-CW12ES-BU
VPC-CW12VAIO
VPC-CW13EG-BU
VPC-CW13FL
VPC-CW13FL-B
VPC-CW13FL-P
VPC-CW13FL-W
VPC-CW13FX
VPC-CW13FX-B
VPC-CW13FX-P
VPC-CW13FX-R
VPC-CW13FX-W
VPC-CW14FX
VPC-CW14FX-B
VPC-CW14FX-P
VPC-CW14FX-R
VPC-CW14FX-W
VPC-CW152C
VPC-CW152C-B
VPC-CW152C-W
VPC-CW15EC-BU
VPC-CW15EC-WU
VPC-CW15FA-B
VPC-CW15FA-P

VPC-CW15FA-W
VPC-CW15FG-B
VPC-CW15FG-P
VPC-CW15FG-W
VPC-CW15FGB
VPC-CW15FGP
VPC-CW15FGW
VPC-CW15FL
VPC-CW15FL-B
VPC-CW15FL-L
VPC-CW15FN-R
VPC-CW15FX
VPC-CW15FX-B
VPC-CW15FX-P
VPC-CW15FX-R
VPC-CW15FX-W
VPC-CW16EC
VPC-CW16EC-B
VPC-CW16EC-L
VPC-CW16EC-P
VPC-CW16EC-R
VPC-CW16EC-W
VPC-CW16FA-B
VPC-CW16FA-L
VPC-CW16FA-P
VPC-CW16FA-R
VPC-CW16FA-W
VPC-CW16FG-B
VPC-CW16FG-L
VPC-CW16FG-P
VPC-CW16FG-R
VPC-CW16FG-W
VPC-CW17FX
VPC-CW17FX-B
VPC-CW17FX-P
VPC-CW17FX-R
VPC-CW17FX-W
VPC-CW18FC-B
VPC-CW18FC-L
VPC-CW18FC-P
VPC-CW18FC-R
VPC-CW18FC-W
VPC-CW18FG-B
VPC-CW18FJ
VPC-CW18FJ-P
VPC-CW18FJ-R
VPC-CW18FJ-W
VPC-CW18FX
VPC-CW18FX-B
VPC-CW18FX-P
VPC-CW18FX-R
VPC-CW18FX-W
VPC-CW19FJ

VPC-CW19FJ-W
VPC-CW1AFJ
VPC-CW1AGG-B
VPC-CW1AGGB
VPC-CW1AHJ
VPC-CW1BGN-BU
VPC-CW1FFX-L
VPC-CW1RFX
VPC-CW1RFX-B
VPC-CW1RFX-P
VPC-CW1RFX-W
VPC-CW1S1E
VPC-CW1S1E-B
VPC-CW1S1E-L
VPC-CW1S1E-P
VPC-CW1S1E-R
VPC-CW1S1E-W
VPC-CW1S1R-B
VPC-CW1S1R-L
VPC-CW1S1R-P
VPC-CW1S1R-R
VPC-CW1S1R-W
VPC-CW1S1T-B
VPC-CW1S1T-L
VPC-CW1S1T-P
VPC-CW1S1T-R
VPC-CW1S1T-W
VPC-CW1TFX
VPC-CW1TFX-B
VPC-CW1TFX-P
VPC-CW1TFX-W
VPC-CW1UFX
VPC-CW1UFX-B
VPC-CW1UFX-P
VPC-CW1UFX-R
VPC-CW1UFX-W
VPC-CW1Z4E
VPC-CW1ZEG-BU
VPC-CW1ZEH-BU
VPC-CW21FX
VPC-CW21FX-B
VPC-CW21FX-L
VPC-CW21FX-P
VPC-CW21FX-R
VPC-CW21FX-W
VPC-CW22FX
VPC-CW22FX-B
VPC-CW22FX-L
VPC-CW22FX-P
VPC-CW22FX-R
VPC-CW22FX-W
VPC-CW23FX
VPC-CW23FX-B

VPC-CW23FX-L
VPC-CW23FX-P
VPC-CW23FX-R
VPC-CW23FX-W
VPC-CW25FG
VPC-CW25FG-P
VPC-CW25FL
VPC-CW26EC
VPC-CW26EC-B
VPC-CW26EC-P
VPC-CW26EC-W
VPC-CW26FA-B
VPC-CW26FA-L
VPC-CW26FA-P
VPC-CW26FA-R
VPC-CW26FA-W
VPC-CW26FG-B
VPC-CW26FG-L
VPC-CW26FG-P
VPC-CW26FG-R
VPC-CW26FG-W
VPC-CW26FH-B
VPC-CW26FH-L
VPC-CW26FH-P
VPC-CW26FH-R
VPC-CW26FH-W
VPC-CW26FX
VPC-CW26FX-B
VPC-CW26FX-L
VPC-CW26FX-P
VPC-CW26FX-R
VPC-CW26FX-W
VPC-CW27FX
VPC-CW27FX-B
VPC-CW27FX-L
VPC-CW27FX-P
VPC-CW27FX-R
VPC-CW27FX-W
VPC-CW28EC
VPC-CW28EC-B
VPC-CW28EC-L
VPC-CW28EC-P
VPC-CW28EC-R
VPC-CW28EC-W
VPC-CW28FG-B
VPC-CW28FJ-P
VPC-CW28FJ-R
VPC-CW28FJ-W
VPC-CW29FJ
VPC-CW29FJ-W
VPC-CW2AFJ
VPC-CW2AGG-B
VPC-CW2AHJ

VPC-CW2BGN-BU
VPC-CW2C5E
VPC-CW2KGX-B
VPC-CW2MFX-PU
VPC-CW2PFX
VPC-CW2PFX-L
VPC-CW2PFX-R
VPC-CW2PFX-W
VPC-CW2S1E
VPC-CW2S1E-B
VPC-CW2S1E-L
VPC-CW2S1E-P
VPC-CW2S1E-R
VPC-CW2S1E-W
VPC-CW2S1R-B
VPC-CW2S1R-L
VPC-CW2S1R-P
VPC-CW2S1R-R
VPC-CW2S1R-W
VPC-CW2S5C
VPC-CW2S5C-CN1
VPC-CW2S8E
VPC-CW2S8E-B
VPC-CW2S8E-W
VPC-CW2Z1E-B
VPC-F110FL
VPC-F111FX
VPC-F111FX-B
VPC-F111FX-H
VPC-F112FX
VPC-F112FX-B
VPC-F112FX-H
VPC-F113FX
VPC-F113FX-B
VPC-F113FX-H
VPC-F114FX
VPC-F114FX-B
VPC-F114FX-H
VPC-F115FG
VPC-F115FG-B
VPC-F115FGB
VPC-F115FM
VPC-F115FM-B
VPC-F116FGBI
VPC-F116FX
VPC-F116FX-B
VPC-F116FX-H
VPC-F117FJ
VPC-F117FJ-W
VPC-F117FX
VPC-F117FX-B
VPC-F117HG-BI
VPC-F117HGBI

VPC-F118FJ
VPC-F118FJ-W
VPC-F119FC
VPC-F119FC-BI
VPC-F119FJ
VPC-F119FJ-BI
VPC-F11A4E
VPC-F11AFJ
VPC-F11AGJ
VPC-F11AHJ
VPC-F11B4E
VPC-F11C4E
VPC-F11C4E-B
VPC-F11C5E
VPC-F11D4E
VPC-F11D4E-H
VPC-F11DGX-B
VPC-F11E1R-H
VPC-F11E4E
VPC-F11E4E-W
VPC-F11GGX-B
VPC-F11HGX
VPC-F11HGX-B
VPC-F11J1E-B
VPC-F11JFX
VPC-F11JFX-B
VPC-F11KFX
VPC-F11KFX-B
VPC-F11KFX-H
VPC-F11LFX
VPC-F11LFX-B
VPC-F11LFX-H
VPC-F11M1E
VPC-F11M1E-H
VPC-F11M1E-W
VPC-F11M1EH
VPC-F11M1EHEE9
VPC-F11M1R-H
VPC-F11MFX
VPC-F11MFX-B
VPC-F11PFX
VPC-F11PFX-H
VPC-F11QFX
VPC-F11QFX-B
VPC-F11QFX-H
VPC-F11S1E
VPC-F11S1E-B
VPC-F11S1R-B
VPC-F11Z1E
VPC-F11Z1E-BI
VPC-F11ZHJ
VPC-F120FL
VPC-F121FX

VPC-F121FX-B
VPC-F121FX-H
VPC-F122FX
VPC-F122FX-B
VPC-F122FX-H
VPC-F123FX
VPC-F123FX-B
VPC-F123FX-H
VPC-F125FX
VPC-F125FX-B
VPC-F125FX-H
VPC-F126FM-B
VPC-F127FDB
VPC-F127FJ-W
VPC-F127FX
VPC-F127FX-B
VPC-F127FX-H
VPC-F127HG
VPC-F127HGBI
VPC-F128FJ-B
VPC-F129FJ-BI
VPC-F12A4E
VPC-F12AFJ
VPC-F12AFM
VPC-F12AFM-H
VPC-F12AGJ
VPC-F12AHJ
VPC-F12B4E
VPC-F12BFX
VPC-F12BFX-B
VPC-F12BFX-H
VPC-F12C4E
VPC-F12C4E-B
VPC-F12C5E
VPC-F12E1E-H
VPC-F12E1E-W
VPC-F12E1R-H
VPC-F12E4E
VPC-F12E4E-B
VPC-F12F4E
VPC-F12F4E-H
VPC-F12GFX
VPC-F12GFX-B
VPC-F12JFX
VPC-F12JFX-B
VPC-F12KFX
VPC-F12KFX-B
VPC-F12LGX-B
VPC-F12M0E-B
VPC-F12M1E-H
VPC-F12M1EHEE9
VPC-F12M1R-H
VPC-F12MGX-H

VPC-F12NGX
VPC-F12NGX-B
VPC-F12PGX
VPC-F12PGX-B
VPC-F12RGX
VPC-F12RGX-B
VPC-F12S1E-B
VPC-F12S1EBEE9
VPC-F12S1R-B
VPC-F12SGX-B
VPC-F12THX-H
VPC-F12XHX
VPC-F12XHX-B
VPC-F12YFX
VPC-F12YFX-B
VPC-F12YFX-H
VPC-F12Z1E
VPC-F12Z1E-BI
VPC-F12Z1EBIEE9
VPC-F131FM
VPC-F131FM-B
VPC-F131FM-H
VPC-F132FX
VPC-F132FX-B
VPC-F132FX-H
VPC-F133FX-B
VPC-F133FX-H
VPC-F134FX
VPC-F134FX-B
VPC-F134FX-H
VPC-F135FG
VPC-F135FG-B
VPC-F135FL
VPC-F136FG
VPC-F136FG-BI
VPC-F136FM
VPC-F136FM-B
VPC-F136FM-H
VPC-F136FX
VPC-F136FX-B
VPC-F136FX-H
VPC-F137
VPC-F137BLACK
VPC-F137FX
VPC-F137FX-B
VPC-F137FX-H
VPC-F137HG
VPC-F137HG-BI
VPC-F138FC-BI
VPC-F138FJ-B
VPC-F139FJ-BI
VPC-F13A4E
VPC-F13A4E-H

VPC-F13AFJ
VPC-F13AFX
VPC-F13AFX-B
VPC-F13AGJ
VPC-F13AHJ
VPC-F13B4E
VPC-F13BFX
VPC-F13BFX-B
VPC-F13C4E
VPC-F13C4E-B
VPC-F13C5E
VPC-F13CGX-B
VPC-F13D4E
VPC-F13D4E-B
VPC-F13DGX-B
VPC-F13E1E-H
VPC-F13E1R-H
VPC-F13E4E
VPC-F13E4E-H
VPC-F13E8E
VPC-F13E8E-H
VPC-F13E8R
VPC-F13E8R-H
VPC-F13EFX-B
VPC-F13F4E
VPC-F13FGX-B
VPC-F13GGX-B
VPC-F13HFX-B
VPC-F13J0E
VPC-F13J0E-H
VPC-F13J8E
VPC-F13J8E-H
VPC-F13JFX-B
VPC-F13L0E
VPC-F13L0E-H
VPC-F13L4E
VPC-F13L8E
VPC-F13L8E-H
VPC-F13L8EH
VPC-F13L8EH9
VPC-F13LGX-B
VPC-F13M0E-B
VPC-F13M1E
VPC-F13M1E-H
VPC-F13M1EH9
VPC-F13M4E
VPC-F13M4EBIAE
VPC-F13M8E
VPC-F13M8E-B
VPC-F13MGX
VPC-F13MGX-B
VPC-F13NFX
VPC-F13NFX-B

VPC-F13PFX
VPC-F13PFX-B
VPC-F13QFX
VPC-F13QFX-B
VPC-F13RFX
VPC-F13RFX-B
VPC-F13S0E-B
VPC-F13S1E
VPC-F13S1E-B
VPC-F13S1R-B
VPC-F13S8E
VPC-F13S8E-B
VPC-F13S8R
VPC-F13S8R-B
VPC-F13SFX
VPC-F13SFX-B
VPC-F13UFX
VPC-F13UFX-B
VPC-F13UFX-H
VPC-F13WFX
VPC-F13WFX-B
VPC-F13WFX-BC
VPC-F13WFX-H
VPC-F13X5E
VPC-F13XFX
VPC-F13XFX-B
VPC-F13YFX
VPC-F13YFX-B
VPC-F13YFX-H
VPC-F13Z0E
VPC-F13Z0E-B
VPC-F13Z1E-B
VPC-F13Z1EBEE9
VPC-F13Z8E
VPC-F13Z8E-BI
VPC-F13Z8R
VPC-F13ZHJ
VPC-F148FJ-B
VPC-F149FJ-BI
VPC-F14AFJ
VPC-F14AGJ
VPC-F14AHJ
VPC-F14ZHJ
VPC-F215FDBI
VPC-F215FL
VPC-F217HG
VPC-F217HG-BI
VPC-F219FC
VPC-F219FC-BI
VPC-F219FJ-BI
VPC-F21AFJ
VPC-F21AGJ
VPC-F21AHJ

VPC-F21Z1E
VPC-F21Z1E-BI
VPC-F21Z1EBI
VPC-F21Z1EBIEE9
VPC-F21Z1EBIN
VPC-F21Z1R
VPC-F21Z1R-B
VPC-F21ZHJ
VPC-F221FX-B
VPC-F221FX-S
VPC-F223FX-B
VPC-F224FDB
VPC-F224FX-B
VPC-F224FX-S
VPC-F226FJ-S
VPC-F226FM-B
VPC-F227FJ-B
VPC-F227FX-B
VPC-F229FJ-BI
VPC-F22AJ
VPC-F22C5E
VPC-F22E1R
VPC-F22E1R-B
VPC-F22FGX-B
VPC-F22J1E
VPC-F22J1E-B
VPC-F22KFX-B
VPC-F22L1E
VPC-F22L1E-B
VPC-F22L1EBEE9

VPC-F22L1EBEE96GB
VPC-F22M0E
VPC-F22M0E-B
VPC-F22M1E
VPC-F22M1E-B
VPC-F22M1R
VPC-F22M1R-B
VPC-F22S1E
VPC-F22S1E-B
VPC-F22S1EB
VPC-F22S1EBEE9
VPC-F22S1R
VPC-F22S1R-B
VPC-F22S8E
VPC-F22S8E-B
VPC-F22SFX-W
VPC-F232FX-B
VPC-F233FX-B
VPC-F234FX-B
VPC-F235FDB
VPC-F235FW

VPC-F235FW-B
VPC-F236HG
VPC-F236HW
VPC-F236HW-B
VPC-F237
VPC-F237FJ-S
VPC-F237FX
VPC-F237FX-B
VPC-F237HG
VPC-F237HW
VPC-F237HW-BI
VPC-F238FJ-B
VPC-F23A9E-B
VPC-F23AJ
VPC-F23CGX-B
VPC-F23K1E
VPC-F23L1E
VPC-F23L1E-B
VPC-F23L1EB
VPC-F23M1E
VPC-F23M1E-B
VPC-F23M1EBEE9

VPC-F23M1EBEE98GB
VPC-F23M1R
VPC-F23M1R-B
VPC-F23N1E
VPC-F23N1E-B
VPC-F23P1E
VPC-F23P1E-B
VPC-F23P1EB
VPC-F23Q1E
VPC-F23Q1E-B
VPC-F23S1E
VPC-F23S1E-B
VPC-F23S1EBEE9
VPC-F23S1R
VPC-F23S1R-B
VPC-F23X1R
VPC-F23Z1E
VPC-F23Z1E-B
VPC-F23Z1R
VPC-F244FDS
VPC-F247FJ-S
VPC-F248FJ-B
VPC-F249FJ-BI
VPC-F24AJ
VPC-F24L1E
VPC-F24L1E-B
VPC-F24L1EB
VPC-F24M1E
VPC-F24M1E-B

VPC-F24M1EBEE9
VPC-F24M1R
VPC-F24M1R-B
VPC-F24N1E
VPC-F24N1E-B
VPC-F24P1E
VPC-F24P1E-B
VPC-F24Q1E
VPC-F24Q1E-B
VPC-M11M1E-B
VPC-M11M1E-W
VPC-M120AL-L
VPC-M120AL-P
VPC-M121ADP
VPC-M125AG-L
VPC-M125AG-P
VPC-M125AG-W
VPC-M125AGP
VPC-M126AA-L
VPC-M126AA-P
VPC-M126AA-W
VPC-M126AG-L
VPC-M126AG-P
VPC-M126AG-W
VPC-M126AH-L
VPC-M126AH-P
VPC-M126AH-W
VPC-M129AJ-L
VPC-M129AJ-P
VPC-M129AJ-W
VPC-M12M1E
VPC-M12M1E-L
VPC-M12M1E-P
VPC-M12M1E-W
VPC-M12M1EWEE9
VPC-M12M1R-L
VPC-M12M1R-P
VPC-M12M1R-W
VPC-M13M1E
VPC-M13M1E-L
VPC-M13M1E-P
VPC-M13M1E-W
VPC-M13M1EL
VPC-M13M1ELEE9
VPC-M13M1EP
VPC-M13M1EPEE9
VPC-M13M1EW
VPC-M13M1EWEE9
VPC-M13M1R-L
VPC-M13M1R-P
VPC-M13M1R-W
VPC-S110FL
VPC-S110FL-B

VPC-S110FL-P
VPC-S111FM-S
VPC-S113FG-B
VPC-S113FGB
VPC-S115EC
VPC-S115FG
VPC-S116FG
VPC-S116FG-B
VPC-S117GG
VPC-S117GG-B
VPC-S117GGB
VPC-S118EC
VPC-S119FJ
VPC-S119FJ-B
VPC-S119GC
VPC-S11A7E
VPC-S11A7E-B
VPC-S11AFJ
VPC-S11AGJ
VPC-S11AHJ
VPC-S11AVJ
VPC-S11B7E
VPC-S11C5E
VPC-S11D7E
VPC-S11D7E-B
VPC-S11E7E
VPC-S11F7E
VPC-S11G7E
VPC-S11H7E
VPC-S11J7E
VPC-S11J7E-B
VPC-S11M1E
VPC-S11M1E-W
VPC-S11M9R-B
VPC-S11V9E
VPC-S11V9E-B
VPC-S11V9R-B
VPC-S11X9E
VPC-S11X9E-B
VPC-S11X9R-S
VPC-S120FL
VPC-S120FL-B
VPC-S120FL-V
VPC-S121GL
VPC-S123FGB
VPC-S125EC
VPC-S128EC
VPC-S129FJ-B
VPC-S129FJ-S
VPC-S129GC
VPC-S12A7E
VPC-S12A7E-B
VPC-S12A7R

VPC-S12AFJ
VPC-S12AGJ
VPC-S12AHJ
VPC-S12AVJ
VPC-S12B7E
VPC-S12C5E
VPC-S12C7E
VPC-S12C7E-B
VPC-S12D7E
VPC-S12E7E
VPC-S12F7E
VPC-S12J1E-W
VPC-S12L9E-B
VPC-S12M9E-B
VPC-S12M9R-S
VPC-S12V9E-B
VPC-S12V9R-B
VPC-S12X9E
VPC-S12X9E-B
VPC-S12X9EBEE9
VPC-S12X9R-B
VPC-S132FX-B
VPC-S132FX-S
VPC-S132GX-B
VPC-S133GN
VPC-S133GN-B
VPC-S134GX-S
VPC-S135EC
VPC-S135EC-B
VPC-S135EC-G
VPC-S135EC-P
VPC-S135FA-B
VPC-S135FG-W
VPC-S135FH-P
VPC-S135FX-B
VPC-S135FX-S
VPC-S136EC
VPC-S136EC-B
VPC-S136EC-G
VPC-S136EC-P
VPC-S136FA-B
VPC-S136FG-B
VPC-S137GA-B
VPC-S137GF
VPC-S137GF-B
VPC-S137GG
VPC-S137GG-B
VPC-S137GH-B
VPC-S138EC
VPC-S138EC-B
VPC-S138EC-G
VPC-S138EC-P
VPC-S139FJ-B

VPC-S139FJ-P
VPC-S139FJ-S
VPC-S139GC
VPC-S139GC-B
VPC-S13A76
VPC-S13A7E
VPC-S13AFG
VPC-S13AFG-B
VPC-S13AFG-G
VPC-S13AFG-P
VPC-S13AFG-W
VPC-S13AFH-B
VPC-S13AFH-W
VPC-S13AFJ
VPC-S13AGJ
VPC-S13AHJ
VPC-S13B7E
VPC-S13C5E
VPC-S13CGX-B
VPC-S13DGX-B
VPC-S13EGX-B
VPC-S13GGX-B
VPC-S13I7E
VPC-S13L8E
VPC-S13L8E-B
VPC-S13L9E-B
VPC-S13L9EBEE9
VPC-S13M1E
VPC-S13M1E-W
VPC-S13M1EW
VPC-S13S8R
VPC-S13S8R-S
VPC-S13S9E-B
VPC-S13S9R-S
VPC-S13V9E-B
VPC-S13X8E
VPC-S13X8E-B
VPC-S13X9E-B
VPC-S13X9R-B
VPC-S13Z9R-B
VPC-S149FJ-B
VPC-S149FJ-P
VPC-S149FJ-S
VPC-S14AFJ
VPC-S14AGJ
VPC-S14AHJ
VPC-S14M
VPC-Y110FL-B
VPC-Y115FG-S
VPC-Y115FGS
VPC-Y115FX-B
VPC-Y115FX-BI
VPC-Y115FXBI

VPC-Y118EC
VPC-Y118GX-BI
VPC-Y119FJ
VPC-Y119FJ-S
VPC-Y11AFJ
VPC-Y11AGJ
VPC-Y11AHJ
VPC-Y11AVJ
VPC-Y11M1E
VPC-Y11M1E-S
VPC-Y11M1R-S
VPC-Y11S1E
VPC-Y11S1E-S
VPC-Y11V9E
VPC-Y11V9E-S
VPC-Y216FX
VPC-Y216FX-B
VPC-Y216FX-G
VPC-Y216FX-L
VPC-Y216FX-P
VPC-Y216FX-S
VPC-Y216FX-V
VPC-Y216GX
VPC-Y216GX-B
VPC-Y216GX-G
VPC-Y216GX-L
VPC-Y216GX-P
VPC-Y216GX-S
VPC-Y216GX-V
VPC-Y218EC-BI
VPC-Y218EC-G
VPC-Y218EC-L
VPC-Y218EC-P
VPC-Y218EC-R
VPC-Y219FJ-S
VPC-Y21A7E
VPC-Y21AFJ
VPC-Y21AFX-B
VPC-Y21AGJ
VPC-Y21AHJ
VPC-Y21AVJ
VPC-Y21B7E
VPC-Y21BGX-B
VPC-Y21C5E
VPC-Y21EFX-B
VPC-Y21EFX-V
VPC-Y21M1R-G
VPC-Y21M1R-L
VPC-Y21M1R-P
VPC-Y21M1R-V
VPC-Y21S1E-G
VPC-Y21S1E-L
VPC-Y21S1E-P

VPC-Y21S1E-S
VPC-Y21S1E-SI
VPC-Y21S1ESIEE9
VPC-Y21SFX-R
VPC-Y21V9E-B
VPC-Y22C5E
VPC-Y22Z5008B
VPC-Y22Z5009Q
VPC-Y22Z5010B
VPC-YA15EC
VPC-YA15EC-B
VPC-YA15EC-R
VPC-YA15FG
VPC-YA15FG-B
VPC-YA15FG-R
VPC-YA15FH-B
VPC-YA15FH-R
VPC-YA16EC
VPC-YA16EC-B
VPC-YA16EC-R
VPC-YA16FW
VPC-YA17GG
VPC-YA17GG-B
VPC-YA17GG-R
VPC-YA17GH-B
VPC-YA17GH-R
VPC-YA17GW
VPC-YA19FJ-B
VPC-YA1C5E
VPC-YA1V9E
VPC-YA1V9E-B
VPC-YA1V9R
VPC-YA1V9R-B
VPC-YA25EC
VPC-YA26EC
VPC-YA2AJ
VPC-YB10AL-P
VPC-YB10AL-S
VPC-YB13KDS
VPC-YB13KX
VPC-YB13KX-G
VPC-YB13KX-P
VPC-YB13KX-S
VPC-YB14KX
VPC-YB14KX-G
VPC-YB14KX-P
VPC-YB14KX-S
VPC-YB15AG
VPC-YB15AG-G
VPC-YB15AG-P
VPC-YB15AG-S
VPC-YB15AH-G
VPC-YB15AH-P

VPC-YB15AH-S
VPC-YB15AL
VPC-YB15AL-P
VPC-YB15AL-S
VPC-YB15JC
VPC-YB15KX
VPC-YB15KX-G
VPC-YB15KX-P
VPC-YB15KX-S
VPC-YB15KXP
VPC-YB16KG-G
VPC-YB16KG-P
VPC-YB16KG-S
VPC-YB19KJ-G
VPC-YB19KJ-P
VPC-YB19KJ-S
VPC-YB1S1E
VPC-YB1S1E-S
VPC-YB1S1ESASIS
VPC-YB1S1ESEE9
VPC-YB1S1R
VPC-YB1S1R-S
VPC-YB20AL
VPC-YB20AL-B
VPC-YB20AL-P
VPC-YB29KJ-G
VPC-YB29KJ-P
VPC-YB29KJ-S
VPC-YB2L1R
VPC-YB2L1R-B
VPC-YB2L1R-G
VPC-YB2L1R-P
VPC-YB2L1R-S
VPC-YB2M1E
VPC-YB2M1E-G
VPC-YB2M1E-P
VPC-YB2M1E-S
VPC-YB2M1EGEE9
VPC-YB2M1EP
VPC-YB2M1EPEE9
VPC-YB2M1ES
VPC-YB2M1ESEE9
VPC-YB33KDB
VPC-YB33KX-B
VPC-YB33KX-P
VPC-YB33KX-S
VPC-YB35AL
VPC-YB35AL-S
VPC-YB35AN-B
VPC-YB35JC
VPC-YB35KX
VPC-YB35KX-B
VPC-YB35KX-P

VPC-YB35KX-S
VPC-YB35KXS
VPC-YB36KG
VPC-YB36KGP
VPC-YB36KW
VPC-YB36KW-P
VPC-YB36KW-S
VPC-YB3Q1R
VPC-YB3Q1R-B
VPC-YB3Q1R-G
VPC-YB3Q1R-P
VPC-YB3Q1R-S
VPC-YB3V1E
VPC-YB3V1E-G
VPC-YB3V1E-P
VPC-YB3V1E-S
VPC-YB3V1EGEE9
VPC-YB3V1EP
VPC-YB3V1EPEE9
VPC-YB3V1ESEE9
VPC-YB45JB
VPC-YB45JB-B
VPC-YB45JB-P

Â



IMBALLAGGIO SICURO

in busta elettrostatica con protezioni antiurto



ATTENZIONE: ricorda di conservare l'imballo originale

Solo così potrai avvalerti della garanzia e del diritto di recesso

In conformità alla normativa italiana in materia di restituzioni, non si accetteranno in nessuna circostanza resi privi della confezione integra in tutte le sue parti.



ISTRUZIONI

PER L'USO



NON SCARICARE LA CARICA RESIDUA
appena acquistata metti subito in carica la batteria



FAI 3 CICLI DI CARICA DA 8 ORE
servirà alla batteria per attivarsi chimicamente



STACCA L'ALIMENTATORE QUANDO SEI AL 100%
dal 4° ciclo stacca sempre dall'rete la batteria appena
per caricarla mai completamente alla 0%

[Informazioni Venditore](#)

Recensioni Clienti: Nessuna recensione disponibile per questo prodotto.
Autenticati per poter scrivere una recensione.