

## **SONY VAIO > Batteria DURACELL per BPS13 (10,8/11,1V) > marchio 2POWER**

€64,60 (incluso 22 % I.V.A.)



# SONY

# VAIO

compatibile



*stesse dimensioni!  
stessi parametri elettrici*



## 2-POWER®

# ALTA QUALITÀ'

0,02% di fake contro il 2% delle normali compatibili



À  
À

## CERCA



il **CODICE** sulla tua batteria!  
è l'**UNICO** che individua al  
**100%** il tuo modello.

Model: BATEFL50L9C72

## ATTENTO AL VOLTAGGIO

batterie da 10,8/11,1V **NON FUNZIONANO** su pc da 14,4/14,8V e viceversa!

NB: le immagini sono puramente indicative di forma e dimensioni dell'oggetto. Fanno fede le specifiche riportate nell'inserzione.

â-° Compatibile con le seguenti batterie:

Â

VGP-BPS13  
VGP-BPS13-B  
VGP-BPS13-Q  
VGP-BPS13-S  
VGP-BPS13A-B  
VGP-BPS13A-Q  
VGP-BPS13A-S  
VGP-BPS13AB  
VGP-BPS13AQ  
VGP-BPS13AS  
VGP-BPS13B-B  
VGP-BPS13B-Q  
VGP-BPS13B-S  
VGP-BPS13BB  
VGP-BPS13BQ  
VGP-BPS13BS  
VGP-BPS13Q  
VGP-BPS13S  
VGP-BPL13  
VGP-BPL21  
VGP-BPS21  
VGP-BPS21-S  
VGP-BPS21A  
VGP-BPS21A-B  
VGP-BPS21B  
VGP-BSP13-S

Â


Â

Â

Suggerimento  CTRL + F  
per cercare il tuo modello di portatile

 **ATTENTO**

il codice del pc da solo  
**NON E' SUFFICIENTE**  
a stabilire la compatibilità



â-° Compatibile con i seguenti pc portatili:

Â

VGN-AW110J-H  
VGN-AW11M-H  
VGN-AW11S-B  
VGN-AW11XU-Q  
VGN-AW11Z-B  
VGN-AW160J-Q  
VGN-AW170C  
VGN-AW180Y-Q  
VGN-AW19  
VGN-AW19-Q  
VGN-AW21M-H  
VGN-AW21MH  
VGN-AW21S-B  
VGN-AW21SB  
VGN-AW21VY-Q  
VGN-AW21XY-Q  
VGN-AW21XYQ  
VGN-AW21Z-B  
VGN-AW21ZB  
VGN-AW220J-H  
VGN-AW230J-H  
VGN-AW235J-B  
VGN-AW270Y-Q  
VGN-AW27GY-QE1  
VGN-AW290JFQ  
VGN-AW310J-H  
VGN-AW31M  
VGN-AW31M-H  
VGN-AW31MH  
VGN-AW31S-B  
VGN-AW31XY-O  
VGN-AW31XY-Q  
VGN-AW31ZJ  
VGN-AW31ZJ-B  
VGN-AW31ZS-B  
VGN-AW35GJ-H  
VGN-AW35GJH  
VGN-AW37GY-Q  
VGN-AW37GYQ  
VGN-AW390JAH  
VGN-AW390JCH  
VGN-AW41JF  
VGN-AW41JF-H  
VGN-AW41MF  
VGN-AW41MF-H  
VGN-AW41XH  
VGN-AW41XH-Q  
VGN-AW41ZF  
VGN-AW41ZF-B

VGN-AW47GH-Q  
VGN-AW47GHQ  
VGN-AW4MRF-H  
VGN-AW4XRH-Q  
VGN-AW4ZRF-B  
VGN-AW50DB  
VGN-AW50DB-H  
VGN-AW51JGB  
VGN-AW52JGB  
VGN-AW53FB  
VGN-AW70B-Q  
VGN-AW71JB  
VGN-AW72JB  
VGN-AW73FB  
VGN-AW80NS  
VGN-AW80S  
VGN-AW80US  
VGN-AW81DS  
VGN-AW81JS  
VGN-AW81YS  
VGN-AW82DS  
VGN-AW82JS  
VGN-AW82YS  
VGN-AW83FS  
VGN-AW83GS  
VGN-AW83HS  
VGN-AW90NS  
VGN-AW90S  
VGN-AW90US  
VGN-AW91CDS  
VGN-AW91CJS  
VGN-AW91CYS  
VGN-AW91DS  
VGN-AW91JS  
VGN-AW91YS  
VGN-AW92CDS  
VGN-AW92CJS  
VGN-AW92CYS  
VGN-AW92DS  
VGN-AW92JS  
VGN-AW92YS  
VGN-AW93FS  
VGN-AW93GS  
VGN-AW93HS  
VGN-AW93ZFS  
VGN-AW93ZGS  
VGN-AW93ZHS  
VGN-BZ1  
VGN-BZ11EN  
VGN-BZ11M-N  
VGN-BZ11MN  
VGN-BZ11VN  
VGN-BZ11XN

VGN-BZ12EN  
VGN-BZ12V-N  
VGN-BZ12VN  
VGN-BZ12XN  
VGN-BZ13VN  
VGN-BZ13XN  
VGN-BZ153N  
VGN-BZ153N-E1  
VGN-BZ15GN  
VGN-BZ16GN  
VGN-BZ2  
VGN-BZ21VN  
VGN-BZ21XN  
VGN-BZ26M  
VGN-BZ26V  
VGN-BZ26X  
VGN-BZ31VT  
VGN-BZ31XT  
VGN-BZ540N-B  
VGN-BZ560CTO  
VGN-BZ560N22  
VGN-BZ560N24  
VGN-BZ560N26  
VGN-BZ560N30  
VGN-BZ560N32  
VGN-BZ560N34  
VGN-BZ563P23  
VGN-BZ563P29  
VGN-BZ563P30  
VGN-BZ569P26  
VGN-BZ569P36  
VGN-BZ569P38  
VGN-BZ569P40  
VGN-BZ569P44  
VGN-BZ569P45  
VGN-BZ569P46  
VGN-BZ569P47  
VGN-CS1  
VGN-CS11S-P  
VGN-CS11S-Q  
VGN-CS11S-T  
VGN-CS11S-W  
VGN-CS11Z-R  
VGN-CS11Z-T  
VGN-CS13H-P  
VGN-CS13H-Q  
VGN-CS13H-R  
VGN-CS13H-W  
VGN-CS16T-P  
VGN-CS16T-Q  
VGN-CS16T-R  
VGN-CS16T-T  
VGN-CS16T-W

VGN-CS16Z  
VGN-CS170F-P  
VGN-CS170F-Q  
VGN-CS170F-R  
VGN-CS17H-Q  
VGN-CS17H-W  
VGN-CS19-P  
VGN-CS19-Q  
VGN-CS19-R  
VGN-CS19-W  
VGN-CS190JTP  
VGN-CS190JTQ  
VGN-CS190JTR  
VGN-CS190JTT  
VGN-CS190JTW  
VGN-CS2  
VGN-CS204J-W  
VGN-CS215J-Q  
VGN-CS215J-R  
VGN-CS21S  
VGN-CS21S-P  
VGN-CS21S-R  
VGN-CS21S-T  
VGN-CS21S-V  
VGN-CS21S-W  
VGN-CS21SP  
VGN-CS21SR  
VGN-CS21SV  
VGN-CS21SVEE9  
VGN-CS21Z-Q  
VGN-CS220DP  
VGN-CS220DQ  
VGN-CS220DR  
VGN-CS220DT  
VGN-CS220DW  
VGN-CS230J-P  
VGN-CS230J-W  
VGN-CS23H-S  
VGN-CS23T-Q  
VGN-CS23T-W  
VGN-CS25H  
VGN-CS25H-C  
VGN-CS25H-P  
VGN-CS25H-Q  
VGN-CS25H-R  
VGN-CS25H-W  
VGN-CS260DQ  
VGN-CS260DW  
VGN-CS26GW  
VGN-CS26T-C  
VGN-CS26T-P  
VGN-CS26T-Q  
VGN-CS26T-R

VGN-CS26T-T  
VGN-CS26T-V  
VGN-CS26T-W  
VGN-CS27  
VGN-CS270T-P  
VGN-CS270T-Q  
VGN-CS270T-R  
VGN-CS27C  
VGN-CS27P  
VGN-CS27R  
VGN-CS27W  
VGN-CS28  
VGN-CS28-Q  
VGN-CS280J-Q  
VGN-CS290JEC  
VGN-CS290JEP  
VGN-CS290JEQ  
VGN-CS290JER  
VGN-CS290JEW  
VGN-CS2CN1  
VGN-CS3  
VGN-CS310J-P  
VGN-CS310J-Q  
VGN-CS310J-R  
VGN-CS310J-W  
VGN-CS31GN-B  
VGN-CS31S-P  
VGN-CS31S-Q  
VGN-CS31S-R  
VGN-CS31S-T  
VGN-CS31S-V  
VGN-CS31S-W  
VGN-CS31Z-Q  
VGN-CS320J-Q  
VGN-CS320J-R  
VGN-CS325J-P  
VGN-CS325J-Q  
VGN-CS325J-R  
VGN-CS325J-W  
VGN-CS32GH-B  
VGN-CS32SH-B  
VGN-CS33G-W  
VGN-CS33H  
VGN-CS33H-B  
VGN-CS33H-Z  
VGN-CS33M-Q  
VGN-CS33S-W  
VGN-CS34GH-B  
VGN-CS35GNB  
VGN-CS36GJ-C  
VGN-CS36GJ-I  
VGN-CS36GJ-J  
VGN-CS36GJ-P



VGN-CS36GJ-Q  
VGN-CS36GJ-R  
VGN-CS36GJ-T  
VGN-CS36GJ-U  
VGN-CS36GJ-W  
VGN-CS36GJC  
VGN-CS36GJJ  
VGN-CS36GJR  
VGN-CS36H  
VGN-CS36H-C  
VGN-CS36H-P  
VGN-CS36H-Q  
VGN-CS36H-R  
VGN-CS36H-W  
VGN-CS36MJ-J  
VGN-CS36SJ-P  
VGN-CS36TJ-C  
VGN-CS36TJ-J  
VGN-CS36TJ-P  
VGN-CS36TJ-Q  
VGN-CS36TJ-R  
VGN-CS36TJ-T  
VGN-CS36TJ-U  
VGN-CS36TJ-V  
VGN-CS36TJ-W  
VGN-CS385J-Q  
VGN-CS385J-R  
VGN-CS38GD-B  
VGN-CS39  
VGN-CS39-J  
VGN-CS39-U  
VGN-CS390JDV  
VGN-CS3AGH-P  
VGN-CS50B  
VGN-CS50B-W  
VGN-CS51B  
VGN-CS51B-W  
VGN-CS52JB  
VGN-CS52JB-W  
VGN-CS60B  
VGN-CS60B-P  
VGN-CS60B-Q  
VGN-CS60B-R  
VGN-CS61B  
VGN-CS61B-P  
VGN-CS61B-Q  
VGN-CS61B-R  
VGN-CS62JB  
VGN-CS62JB-P  
VGN-CS62JB-Q  
VGN-CS62JB-R  
VGN-CS71B  
VGN-CS71B-W

VGN-CS72JB  
VGN-CS72JB-W  
VGN-CS90HS  
VGN-CS90NS  
VGN-CS90S  
VGN-CS91HS  
VGN-CS91NS  
VGN-CS91S  
VGN-CS92  
VGN-CS92DS  
VGN-CS92JS  
VGN-CS92XS  
VGN-FW11  
VGN-FW11E  
VGN-FW11ER  
VGN-FW11J  
VGN-FW11L  
VGN-FW11LR  
VGN-FW11M  
VGN-FW11MR  
VGN-FW11S  
VGN-FW11SR  
VGN-FW11ZRU  
VGN-FW11ZU  
VGN-FW130EW  
VGN-FW130NW  
VGN-FW139E-H  
VGN-FW139EH  
VGN-FW139NW  
VGN-FW140EH  
VGN-FW140EW  
VGN-FW140NW  
VGN-FW145E-W  
VGN-FW145EW  
VGN-FW150EW  
VGN-FW15T  
VGN-FW160EH  
VGN-FW17  
VGN-FW17-B  
VGN-FW170JH  
VGN-FW17T-H  
VGN-FW17W  
VGN-FW180EH  
VGN-FW19  
VGN-FW19-B  
VGN-FW190EBH  
VGN-FW190EDH  
VGN-FW198UH  
VGN-FW21E  
VGN-FW21ER  
VGN-FW21I  
VGN-FW21J  
VGN-FW21L

VGN-FW21M  
VGN-FW21MR  
VGN-FW21SR  
VGN-FW21Z  
VGN-FW21ZR  
VGN-FW235J  
VGN-FW260F-E  
VGN-FW260FE  
VGN-FW27-B  
VGN-FW27-W  
VGN-FW270J-W  
VGN-FW280F-Y  
VGN-FW280FY  
VGN-FW29-B  
VGN-FW290JRB  
VGN-FW290JTB  
VGN-FW290JTH  
VGN-FW290JTW  
VGN-FW290JVH  
VGN-FW3  
VGN-FW30B  
VGN-FW31E  
VGN-FW31J  
VGN-FW31M  
VGN-FW31MEE9  
VGN-FW31ZJ  
VGN-FW32J  
VGN-FW340DW  
VGN-FW340J-B  
VGN-FW340J-H  
VGN-FW350DH  
VGN-FW350J-B  
VGN-FW350J-H  
VGN-FW351J-H  
VGN-FW355J-H  
VGN-FW35F  
VGN-FW35F-B  
VGN-FW35F-W  
VGN-FW36TJ-B  
VGN-FW370J-H  
VGN-FW373DW  
VGN-FW378J-B  
VGN-FW37J  
VGN-FW37J-B  
VGN-FW390JFB  
VGN-FW390YFB  
VGN-FW390YLH  
VGN-FW398Y-H  
VGN-FW4  
VGN-FW41E-H  
VGN-FW41E-W  
VGN-FW41EH  
VGN-FW41EHEE9

VGN-FW41EWFR  
VGN-FW41J  
VGN-FW41J-H  
VGN-FW41M  
VGN-FW41M-H  
VGN-FW41MH  
VGN-FW41ZJ  
VGN-FW41ZJ-H  
VGN-FW41ZJFR  
VGN-FW41ZJH  
VGN-FW43G-W  
VGN-FW43GB  
VGN-FW43GW  
VGN-FW44MR  
VGN-FW450J-B  
VGN-FW455J-B  
VGN-FW455J-H  
VGN-FW45GJ-B  
VGN-FW45GJB  
VGN-FW45MJ-B  
VGN-FW45TJ-B  
VGN-FW460J-B  
VGN-FW460J-H  
VGN-FW460J-T  
VGN-FW465J-B  
VGN-FW46GJ-B  
VGN-FW46GJ-BE1  
VGN-FW46GJB  
VGN-FW46M  
VGN-FW46S  
VGN-FW46SJ-B  
VGN-FW46Z  
VGN-FW47GY-H  
VGN-FW47GYH  
VGN-FW485J-H  
VGN-FW48E-H  
VGN-FW5  
VGN-FW50B  
VGN-FW510F-H  
VGN-FW51B  
VGN-FW51B-W  
VGN-FW51JF-H  
VGN-FW51JFH  
VGN-FW51MF  
VGN-FW51MF-H  
VGN-FW51ZF  
VGN-FW51ZF-H  
VGN-FW52JB  
VGN-FW53GF-B  
VGN-FW53GF-W  
VGN-FW53GFB  
VGN-FW53GFW  
VGN-FW54E

VGN-FW54FB  
VGN-FW54J  
VGN-FW54M  
VGN-FW54MR  
VGN-FW54S  
VGN-FW55GF-B  
VGN-FW55GFB  
VGN-FW56002B  
VGN-FW56003B  
VGN-FW56004B  
VGN-FW56E  
VGN-FW56GF-B  
VGN-FW56GFB  
VGN-FW56J  
VGN-FW56M  
VGN-FW56SR  
VGN-FW56Z  
VGN-FW56ZR  
VGN-FW57GH-H  
VGN-FW57GHH  
VGN-FW5ERF-H  
VGN-FW5JTF-H  
VGN-FW5MTF-H  
VGN-FW5ZRF-H  
VGN-FW5ZTF-H  
VGN-FW70DB  
VGN-FW71DB  
VGN-FW71DB-W  
VGN-FW72JGB  
VGN-FW73JGB  
VGN-FW74FB  
VGN-FW81HS  
VGN-FW81NS  
VGN-FW81S  
VGN-FW82DS  
VGN-FW82JS  
VGN-FW82XS  
VGN-FW83DS  
VGN-FW83JS  
VGN-FW83XS  
VGN-FW90HS  
VGN-FW90NS  
VGN-FW90S  
VGN-FW91NS  
VGN-FW91S  
VGN-FW92DS  
VGN-FW92JS  
VGN-FW93DS  
VGN-FW93JS  
VGN-FW93XS  
VGN-FW94FS  
VGN-FW94GS  
VGN-FW94HS

VGN-NS110E  
VGN-NS110E-S  
VGN-NS11M-S  
VGN-NS11S  
VGN-NS11S-S  
VGN-NS11Z  
VGN-NS11Z-S  
VGN-NS12M-W  
VGN-NS140E-S  
VGN-NS15G-S  
VGN-NS15H-S  
VGN-NS160E-S  
VGN-NS190J-S  
VGN-NS190J-W  
VGN-NS20E-P  
VGN-NS20E-S  
VGN-NS20J-S  
VGN-NS20M-S  
VGN-NS20S-S  
VGN-NS20Z-S  
VGN-NS215N-S  
VGN-NS21E-S  
VGN-NS21M  
VGN-NS21M-P  
VGN-NS21M-S  
VGN-NS21M-W  
VGN-NS21MW  
VGN-NS21S  
VGN-NS21S-S  
VGN-NS21S-W  
VGN-NS21X-S  
VGN-NS21Z-S  
VGN-NS225J-S  
VGN-NS230DP  
VGN-NS230DW  
VGN-NS230E  
VGN-NS230E-L  
VGN-NS230E-P  
VGN-NS230E-S  
VGN-NS230E-W  
VGN-NS235J  
VGN-NS235J-L  
VGN-NS235J-P  
VGN-NS235J-S  
VGN-NS235J-W  
VGN-NS240DP  
VGN-NS240DS  
VGN-NS240DW  
VGN-NS255DS  
VGN-NS25G-E1  
VGN-NS25G-P  
VGN-NS25G-S  
VGN-NS25GP

VGN-NS290J-L  
VGN-NS290J-S  
VGN-NS290J-W  
VGN-NS295J-S  
VGN-NS30  
VGN-NS305D-S  
VGN-NS30E-P  
VGN-NS30E-S  
VGN-NS30E-W  
VGN-NS30Z-S  
VGN-NS315D-S  
VGN-NS31EH-S  
VGN-NS31EHS  
VGN-NS31M-P  
VGN-NS31M-S  
VGN-NS31M-W  
VGN-NS31MW  
VGN-NS31MWFR  
VGN-NS31MWG4  
VGN-NS31S-S  
VGN-NS328J-L  
VGN-NS328J-W  
VGN-NS36E  
VGN-NS38E-S  
VGN-NS38M-P  
VGN-NS38M-W  
VGN-NS38MPG4  
VGN-NS38MWG4  
VGN-NS50B-L  
VGN-NS50B-W  
VGN-NS51B  
VGN-NS51B-L  
VGN-NS51B-P  
VGN-NS51B-W  
VGN-NS52JB  
VGN-NS52JB-L  
VGN-NS52JB-P  
VGN-NS52JB-W  
VGN-NS70B  
VGN-NS70B-W  
VGN-NS71B  
VGN-NS71B-W  
VGN-NS72JB  
VGN-NS72JB-W  
VGN-NS90HS  
VGN-NS92JS  
VGN-NS92XS SONY  
VAIO VGN-NW  
VGN-NW11  
VGN-NW11S  
VGN-NW11S-S  
VGN-NW11S-T  
VGN-NW11Z-S

VGN-NW11Z-T  
VGN-NW120J-S  
VGN-NW120J-W  
VGN-NW12Z  
VGN-NW12Z-S  
VGN-NW12Z-T  
VGN-NW130J-S  
VGN-NW130J-T  
VGN-NW130J-W  
VGN-NW13GH-T  
VGN-NW150J-S  
VGN-NW150J-T  
VGN-NW15G-T  
VGN-NW15GS  
VGN-NW15GT  
VGN-NW15GW  
VGN-NW160J-S  
VGN-NW17GJ-S  
VGN-NW17GJS  
VGN-NW180J-S  
VGN-NW20EF-P  
VGN-NW20EF-S  
VGN-NW20EF-W  
VGN-NW20SF-P  
VGN-NW20SF-S  
VGN-NW20ZF-S  
VGN-NW215T  
VGN-NW215T-S  
VGN-NW21EF  
VGN-NW21EF-S  
VGN-NW21JF  
VGN-NW21JF-S  
VGN-NW21MF  
VGN-NW21MF-P  
VGN-NW21MF-S  
VGN-NW21MF-W  
VGN-NW21SF-S  
VGN-NW21SF-T  
VGN-NW21ZF  
VGN-NW21ZF-S  
VGN-NW21ZF-T  
VGN-NW230T  
VGN-NW23GF-P  
VGN-NW23GFP  
VGN-NW240F  
VGN-NW240F-P  
VGN-NW240F-S  
VGN-NW24EG  
VGN-NW24JG  
VGN-NW24MG  
VGN-NW24MR  
VGN-NW24S  
VGN-NW25GF-B



VGN-NW25GF-P  
VGN-NW25GF-S  
VGN-NW25GF-T  
VGN-NW25GF-W  
VGN-NW25GFB  
VGN-NW25GFP  
VGN-NW25GFS  
VGN-NW25GFT  
VGN-NW25GFW  
VGN-NW26003B  
VGN-NW26E  
VGN-NW26EG  
VGN-NW26JG  
VGN-NW26M  
VGN-NW26MRG  
VGN-NW270F-S  
VGN-NW270T  
VGN-NW270T-B  
VGN-NW275F  
VGN-NW29GF-B  
VGN-NW29GFB  
VGN-NW2ERE-S  
VGN-NW2ETF-S  
VGN-NW2MRE-P  
VGN-NW2MRE-S  
VGN-NW2MTF-S  
VGN-NW2SRF-S  
VGN-NW2STF-T  
VGN-NW2ZRF-N  
VGN-NW31EF  
VGN-NW31EF-S  
VGN-NW31EF-W  
VGN-NW31JF  
VGN-NW31JF-S  
VGN-NW320F-B  
VGN-NW320F-TC  
VGN-NW35E  
VGN-NW35E-B  
VGN-NW35E-P  
VGN-NW35E-W  
VGN-NW380F-S  
VGN-NW380F-T  
VGN-NW50JB  
VGN-NW51FB  
VGN-NW51FB-N  
VGN-NW51FB-W  
VGN-NW70JB  
VGN-NW71FB  
VGN-NW71FB-N  
VGN-NW71FB-W  
VGN-NW91FS  
VGN-NW91GS  
VGN-NW91VS

VGN-SR11M  
VGN-SR11M-R  
VGN-SR11MR  
VGN-SR12G-B  
VGN-SR12G-P  
VGN-SR12G-S  
VGN-SR13  
VGN-SR13-B  
VGN-SR130E-B  
VGN-SR130EB  
VGN-SR130EP  
VGN-SR130ES  
VGN-SR130NB  
VGN-SR13GN-B  
VGN-SR13GN-P  
VGN-SR13GN-S  
VGN-SR140E-S  
VGN-SR140EB  
VGN-SR140EP  
VGN-SR140ES  
VGN-SR140NS  
VGN-SR150FN  
VGN-SR16  
VGN-SR16-P  
VGN-SR16-S  
VGN-SR165E-B  
VGN-SR165E-P  
VGN-SR165E-S  
VGN-SR165EB  
VGN-SR165EP  
VGN-SR165ES  
VGN-SR165NB  
VGN-SR175N-B  
VGN-SR175NB  
VGN-SR18-J  
VGN-SR18-Q  
VGN-SR190EBJ  
VGN-SR190EBQ  
VGN-SR190F  
VGN-SR19VN  
VGN-SR19VRN  
VGN-SR19XN  
VGN-SR210J-H  
VGN-SR21M  
VGN-SR21M-S  
VGN-SR220J-B  
VGN-SR220J-H  
VGN-SR23H-B  
VGN-SR240J-B  
VGN-SR240N-B  
VGN-SR250J-H  
VGN-SR25G-B  
VGN-SR25G-P

VGN-SR25G-S  
VGN-SR25M-B  
VGN-SR25S-B  
VGN-SR25T-P  
VGN-SR25T-S  
VGN-SR26-B  
VGN-SR26-P  
VGN-SR26-S  
VGN-SR26GN-B  
VGN-SR26MN-B  
VGN-SR27TN-B  
VGN-SR28-B  
VGN-SR28-J  
VGN-SR28-Q  
VGN-SR290JTH  
VGN-SR290JTJ  
VGN-SR290JTQ  
VGN-SR290JVB-C  
VGN-SR290JVH-C  
VGN-SR290NTB  
VGN-SR29NV-S  
VGN-SR29VN-S  
VGN-SR29XN-S  
VGN-SR3  
VGN-SR31M-S  
VGN-SR33H  
VGN-SR33H-B  
VGN-SR33H-P  
VGN-SR33H-S  
VGN-SR35G-B  
VGN-SR35G-E1  
VGN-SR35G-P  
VGN-SR35G-S  
VGN-SR35M-B  
VGN-SR35T-B  
VGN-SR35T-P  
VGN-SR35T-S  
VGN-SR36GNS  
VGN-SR36MN-B  
VGN-SR36MN-P  
VGN-SR37M  
VGN-SR37TN-B  
VGN-SR38  
VGN-SR38-B  
VGN-SR38-J  
VGN-SR38-Q  
VGN-SR390NAB  
VGN-SR390NAH  
VGN-SR390YAB  
VGN-SR399PBB  
VGN-SR399PCB  
VGN-SR39D  
VGN-SR39D-J

VGN-SR39D-Q  
VGN-SR39VN-S  
VGN-SR39XN-S  
VGN-SR3CW-B  
VGN-SR3S1  
VGN-SR4  
VGN-SR410J-B  
VGN-SR410J-H  
VGN-SR41M-P  
VGN-SR41M-R  
VGN-SR41M-S  
VGN-SR41M-W  
VGN-SR41VN-H  
VGN-SR420J-B  
VGN-SR420J-H  
VGN-SR43G-B  
VGN-SR43G-N  
VGN-SR43G-P  
VGN-SR43G-W  
VGN-SR43S-B  
VGN-SR43S-P  
VGN-SR45G-B  
VGN-SR45G-N  
VGN-SR45G-P  
VGN-SR45H  
VGN-SR45H-B  
VGN-SR45H-N  
VGN-SR45H-P  
VGN-SR45M-B  
VGN-SR45M-P  
VGN-SR45T-B  
VGN-SR45T-P  
VGN-SR45T-W  
VGN-SR46GD  
VGN-SR46GD-B  
VGN-SR46GD-P  
VGN-SR46GDB  
VGN-SR46GDP  
VGN-SR46MD-B  
VGN-SR46SD-B  
VGN-SR46SD-P  
VGN-SR46TD-B  
VGN-SR46Z  
VGN-SR48J  
VGN-SR48J-B  
VGN-SR48J-J  
VGN-SR490JCN  
VGN-SR49D  
VGN-SR49D-J  
VGN-SR49D-Q  
VGN-SR49VN-H  
VGN-SR49XN-H  
VGN-SR5

VGN-SR51B-P  
VGN-SR51B-S  
VGN-SR51MF-P  
VGN-SR51MF-S  
VGN-SR51MF-W  
VGN-SR51RF-P  
VGN-SR51RF-S  
VGN-SR51RF-W  
VGN-SR530T-F  
VGN-SR530TF  
VGN-SR53GF-B  
VGN-SR53GF-N  
VGN-SR53GF-P  
VGN-SR53GF-W  
VGN-SR53GFB  
VGN-SR53GFW  
VGN-SR53SF-B  
VGN-SR53SF-P  
VGN-SR55GF-B  
VGN-SR55GF-N  
VGN-SR55GF-P  
VGN-SR55MF-B  
VGN-SR55TF-B  
VGN-SR56004H  
VGN-SR56GG-B  
VGN-SR56GG-S  
VGN-SR56GGB  
VGN-SR56GGS  
VGN-SR56MG-B  
VGN-SR56SG-B  
VGN-SR56SG-P  
VGN-SR56XN  
VGN-SR57S  
VGN-SR57V  
VGN-SR57X  
VGN-SR59TG-H  
VGN-SR59VG  
VGN-SR59VG-H  
VGN-SR59XG  
VGN-SR59XG-H  
VGN-SR70B  
VGN-SR70B-S  
VGN-SR72B  
VGN-SR72B-P  
VGN-SR72B-S  
VGN-SR73JB  
VGN-SR73JB-S  
VGN-SR74FB  
VGN-SR74FB-S  
VGN-SR90FS  
VGN-SR90NS  
VGN-SR90S  
VGN-SR90US

VGN-SR91NS  
VGN-SR91PS  
VGN-SR91S  
VGN-SR91US  
VGN-SR92NS  
VGN-SR92PS  
VGN-SR92S  
VGN-SR92US  
VGN-SR93DS  
VGN-SR93JS  
VGN-SR93PS  
VGN-SR93YS  
VGN-SR94FS  
VGN-SR94GS  
VGN-SR94VS  
VPC-B119GJ  
VPC-B119GJ-B  
VPC-B11A7E  
VPC-B11AGJ  
VPC-B11AV  
VPC-B11AVJ  
VPC-B11V9E  
VPC-B11V9E-B  
VPC-B11X9E  
VPC-B11X9E-B  
VPC-CW1  
VPC-CW120A-L  
VPC-CW120AL  
VPC-CW12EN-BU  
VPC-CW12ES-BU  
VPC-CW12VAIO  
VPC-CW13EG-BU  
VPC-CW13FL  
VPC-CW13FL-B  
VPC-CW13FL-P  
VPC-CW13FL-W  
VPC-CW13FX  
VPC-CW13FX-B  
VPC-CW13FX-P  
VPC-CW13FX-R  
VPC-CW13FX-W  
VPC-CW14FX  
VPC-CW14FX-B  
VPC-CW14FX-P  
VPC-CW14FX-R  
VPC-CW14FX-W  
VPC-CW152C  
VPC-CW152C-B  
VPC-CW152C-W  
VPC-CW15EC-BU  
VPC-CW15EC-WU  
VPC-CW15FA-B  
VPC-CW15FA-P

VPC-CW15FA-W  
VPC-CW15FG-B  
VPC-CW15FG-P  
VPC-CW15FG-W  
VPC-CW15FGB  
VPC-CW15FGP  
VPC-CW15FGW  
VPC-CW15FL  
VPC-CW15FL-B  
VPC-CW15FL-L  
VPC-CW15FN-R  
VPC-CW15FX  
VPC-CW15FX-B  
VPC-CW15FX-P  
VPC-CW15FX-R  
VPC-CW15FX-W  
VPC-CW16EC  
VPC-CW16EC-B  
VPC-CW16EC-L  
VPC-CW16EC-P  
VPC-CW16EC-R  
VPC-CW16EC-W  
VPC-CW16FA-B  
VPC-CW16FA-L  
VPC-CW16FA-P  
VPC-CW16FA-R  
VPC-CW16FA-W  
VPC-CW16FG-B  
VPC-CW16FG-L  
VPC-CW16FG-P  
VPC-CW16FG-R  
VPC-CW16FG-W  
VPC-CW17FX  
VPC-CW17FX-B  
VPC-CW17FX-P  
VPC-CW17FX-R  
VPC-CW17FX-W  
VPC-CW18FC-B  
VPC-CW18FC-L  
VPC-CW18FC-P  
VPC-CW18FC-R  
VPC-CW18FC-W  
VPC-CW18FG-B  
VPC-CW18FJ  
VPC-CW18FJ-P  
VPC-CW18FJ-R  
VPC-CW18FJ-W  
VPC-CW18FX  
VPC-CW18FX-B  
VPC-CW18FX-P  
VPC-CW18FX-R  
VPC-CW18FX-W  
VPC-CW19FJ

VPC-CW19FJ-W  
VPC-CW1AFJ  
VPC-CW1AGG-B  
VPC-CW1AGGB  
VPC-CW1AHJ  
VPC-CW1BGN-BU  
VPC-CW1FFX-L  
VPC-CW1RFX  
VPC-CW1RFX-B  
VPC-CW1RFX-P  
VPC-CW1RFX-W  
VPC-CW1S1E  
VPC-CW1S1E-B  
VPC-CW1S1E-L  
VPC-CW1S1E-P  
VPC-CW1S1E-R  
VPC-CW1S1E-W  
VPC-CW1S1R-B  
VPC-CW1S1R-L  
VPC-CW1S1R-P  
VPC-CW1S1R-R  
VPC-CW1S1R-W  
VPC-CW1S1T-B  
VPC-CW1S1T-L  
VPC-CW1S1T-P  
VPC-CW1S1T-R  
VPC-CW1S1T-W  
VPC-CW1TFX  
VPC-CW1TFX-B  
VPC-CW1TFX-P  
VPC-CW1TFX-W  
VPC-CW1UFX  
VPC-CW1UFX-B  
VPC-CW1UFX-P  
VPC-CW1UFX-R  
VPC-CW1UFX-W  
VPC-CW1Z4E  
VPC-CW1ZEG-BU  
VPC-CW1ZEH-BU  
VPC-CW21FX  
VPC-CW21FX-B  
VPC-CW21FX-L  
VPC-CW21FX-P  
VPC-CW21FX-R  
VPC-CW21FX-W  
VPC-CW22FX  
VPC-CW22FX-B  
VPC-CW22FX-L  
VPC-CW22FX-P  
VPC-CW22FX-R  
VPC-CW22FX-W  
VPC-CW23FX  
VPC-CW23FX-B



VPC-CW23FX-L  
VPC-CW23FX-P  
VPC-CW23FX-R  
VPC-CW23FX-W  
VPC-CW25FG  
VPC-CW25FG-P  
VPC-CW25FL  
VPC-CW26EC  
VPC-CW26EC-B  
VPC-CW26EC-P  
VPC-CW26EC-W  
VPC-CW26FA-B  
VPC-CW26FA-L  
VPC-CW26FA-P  
VPC-CW26FA-R  
VPC-CW26FA-W  
VPC-CW26FG-B  
VPC-CW26FG-L  
VPC-CW26FG-P  
VPC-CW26FG-R  
VPC-CW26FG-W  
VPC-CW26FH-B  
VPC-CW26FH-L  
VPC-CW26FH-P  
VPC-CW26FH-R  
VPC-CW26FH-W  
VPC-CW26FX  
VPC-CW26FX-B  
VPC-CW26FX-L  
VPC-CW26FX-P  
VPC-CW26FX-R  
VPC-CW26FX-W  
VPC-CW27FX  
VPC-CW27FX-B  
VPC-CW27FX-L  
VPC-CW27FX-P  
VPC-CW27FX-R  
VPC-CW27FX-W  
VPC-CW28EC  
VPC-CW28EC-B  
VPC-CW28EC-L  
VPC-CW28EC-P  
VPC-CW28EC-R  
VPC-CW28EC-W  
VPC-CW28FG-B  
VPC-CW28FJ-P  
VPC-CW28FJ-R  
VPC-CW28FJ-W  
VPC-CW29FJ  
VPC-CW29FJ-W  
VPC-CW2AFJ  
VPC-CW2AGG-B  
VPC-CW2AHJ

VPC-CW2BGN-BU  
VPC-CW2C5E  
VPC-CW2KGX-B  
VPC-CW2MFX-PU  
VPC-CW2PFX  
VPC-CW2PFX-L  
VPC-CW2PFX-R  
VPC-CW2PFX-W  
VPC-CW2S1E  
VPC-CW2S1E-B  
VPC-CW2S1E-L  
VPC-CW2S1E-P  
VPC-CW2S1E-R  
VPC-CW2S1E-W  
VPC-CW2S1R-B  
VPC-CW2S1R-L  
VPC-CW2S1R-P  
VPC-CW2S1R-R  
VPC-CW2S1R-W  
VPC-CW2S5C  
VPC-CW2S5C-CN1  
VPC-CW2S8E  
VPC-CW2S8E-B  
VPC-CW2S8E-W  
VPC-CW2Z1E-B  
VPC-F110FL  
VPC-F111FX  
VPC-F111FX-B  
VPC-F111FX-H  
VPC-F112FX  
VPC-F112FX-B  
VPC-F112FX-H  
VPC-F113FX  
VPC-F113FX-B  
VPC-F113FX-H  
VPC-F114FX  
VPC-F114FX-B  
VPC-F114FX-H  
VPC-F115FG  
VPC-F115FG-B  
VPC-F115FGB  
VPC-F115FM  
VPC-F115FM-B  
VPC-F116FGBI  
VPC-F116FX  
VPC-F116FX-B  
VPC-F116FX-H  
VPC-F117FJ  
VPC-F117FJ-W  
VPC-F117FX  
VPC-F117FX-B  
VPC-F117HG-BI  
VPC-F117HGBI

VPC-F118FJ  
VPC-F118FJ-W  
VPC-F119FC  
VPC-F119FC-BI  
VPC-F119FJ  
VPC-F119FJ-BI  
VPC-F11A4E  
VPC-F11AFJ  
VPC-F11AGJ  
VPC-F11AHJ  
VPC-F11B4E  
VPC-F11C4E  
VPC-F11C4E-B  
VPC-F11C5E  
VPC-F11D4E  
VPC-F11D4E-H  
VPC-F11DGX-B  
VPC-F11E1R-H  
VPC-F11E4E  
VPC-F11E4E-W  
VPC-F11GGX-B  
VPC-F11HGX  
VPC-F11HGX-B  
VPC-F11J1E-B  
VPC-F11JFX  
VPC-F11JFX-B  
VPC-F11KFX  
VPC-F11KFX-B  
VPC-F11KFX-H  
VPC-F11LFX  
VPC-F11LFX-B  
VPC-F11LFX-H  
VPC-F11M1E  
VPC-F11M1E-H  
VPC-F11M1E-W  
VPC-F11M1EH  
VPC-F11M1EHEE9  
VPC-F11M1R-H  
VPC-F11MFX  
VPC-F11MFX-B  
VPC-F11PFX  
VPC-F11PFX-H  
VPC-F11QFX  
VPC-F11QFX-B  
VPC-F11QFX-H  
VPC-F11S1E  
VPC-F11S1E-B  
VPC-F11S1R-B  
VPC-F11Z1E  
VPC-F11Z1E-BI  
VPC-F11ZHJ  
VPC-F120FL  
VPC-F121FX

VPC-F121FX-B  
VPC-F121FX-H  
VPC-F122FX  
VPC-F122FX-B  
VPC-F122FX-H  
VPC-F123FX  
VPC-F123FX-B  
VPC-F123FX-H  
VPC-F125FX  
VPC-F125FX-B  
VPC-F125FX-H  
VPC-F126FM-B  
VPC-F127FDB  
VPC-F127FJ-W  
VPC-F127FX  
VPC-F127FX-B  
VPC-F127FX-H  
VPC-F127HG  
VPC-F127HGBI  
VPC-F128FJ-B  
VPC-F129FJ-BI  
VPC-F12A4E  
VPC-F12AFJ  
VPC-F12AFM  
VPC-F12AFM-H  
VPC-F12AGJ  
VPC-F12AHJ  
VPC-F12B4E  
VPC-F12BFX  
VPC-F12BFX-B  
VPC-F12BFX-H  
VPC-F12C4E  
VPC-F12C4E-B  
VPC-F12C5E  
VPC-F12E1E-H  
VPC-F12E1E-W  
VPC-F12E1R-H  
VPC-F12E4E  
VPC-F12E4E-B  
VPC-F12F4E  
VPC-F12F4E-H  
VPC-F12GFX  
VPC-F12GFX-B  
VPC-F12JFX  
VPC-F12JFX-B  
VPC-F12KFX  
VPC-F12KFX-B  
VPC-F12LGX-B  
VPC-F12M0E-B  
VPC-F12M1E-H  
VPC-F12M1EHEE9  
VPC-F12M1R-H  
VPC-F12MGX-H

VPC-F12NGX  
VPC-F12NGX-B  
VPC-F12PGX  
VPC-F12PGX-B  
VPC-F12RGX  
VPC-F12RGX-B  
VPC-F12S1E-B  
VPC-F12S1EBEE9  
VPC-F12S1R-B  
VPC-F12SGX-B  
VPC-F12THX-H  
VPC-F12XHX  
VPC-F12XHX-B  
VPC-F12YFX  
VPC-F12YFX-B  
VPC-F12YFX-H  
VPC-F12Z1E  
VPC-F12Z1E-BI  
VPC-F12Z1EBIEE9  
VPC-F131FM  
VPC-F131FM-B  
VPC-F131FM-H  
VPC-F132FX  
VPC-F132FX-B  
VPC-F132FX-H  
VPC-F133FX-B  
VPC-F133FX-H  
VPC-F134FX  
VPC-F134FX-B  
VPC-F134FX-H  
VPC-F135FG  
VPC-F135FG-B  
VPC-F135FL  
VPC-F136FG  
VPC-F136FG-BI  
VPC-F136FM  
VPC-F136FM-B  
VPC-F136FM-H  
VPC-F136FX  
VPC-F136FX-B  
VPC-F136FX-H  
VPC-F137  
VPC-F137BLACK  
VPC-F137FX  
VPC-F137FX-B  
VPC-F137FX-H  
VPC-F137HG  
VPC-F137HG-BI  
VPC-F138FC-BI  
VPC-F138FJ-B  
VPC-F139FJ-BI  
VPC-F13A4E  
VPC-F13A4E-H

VPC-F13AFJ  
VPC-F13AFX  
VPC-F13AFX-B  
VPC-F13AGJ  
VPC-F13AHJ  
VPC-F13B4E  
VPC-F13BFX  
VPC-F13BFX-B  
VPC-F13C4E  
VPC-F13C4E-B  
VPC-F13C5E  
VPC-F13CGX-B  
VPC-F13D4E  
VPC-F13D4E-B  
VPC-F13DGX-B  
VPC-F13E1E-H  
VPC-F13E1R-H  
VPC-F13E4E  
VPC-F13E4E-H  
VPC-F13E8E  
VPC-F13E8E-H  
VPC-F13E8R  
VPC-F13E8R-H  
VPC-F13EFX-B  
VPC-F13F4E  
VPC-F13FGX-B  
VPC-F13GGX-B  
VPC-F13HFX-B  
VPC-F13J0E  
VPC-F13J0E-H  
VPC-F13J8E  
VPC-F13J8E-H  
VPC-F13JFX-B  
VPC-F13L0E  
VPC-F13L0E-H  
VPC-F13L4E  
VPC-F13L8E  
VPC-F13L8E-H  
VPC-F13L8EH  
VPC-F13L8EH9  
VPC-F13LGX-B  
VPC-F13M0E-B  
VPC-F13M1E  
VPC-F13M1E-H  
VPC-F13M1EH9  
VPC-F13M4E  
VPC-F13M4EBIAE  
VPC-F13M8E  
VPC-F13M8E-B  
VPC-F13MGX  
VPC-F13MGX-B  
VPC-F13NFX  
VPC-F13NFX-B

VPC-F13PFX  
VPC-F13PFX-B  
VPC-F13QFX  
VPC-F13QFX-B  
VPC-F13RFX  
VPC-F13RFX-B  
VPC-F13S0E-B  
VPC-F13S1E  
VPC-F13S1E-B  
VPC-F13S1R-B  
VPC-F13S8E  
VPC-F13S8E-B  
VPC-F13S8R  
VPC-F13S8R-B  
VPC-F13SFX  
VPC-F13SFX-B  
VPC-F13UFX  
VPC-F13UFX-B  
VPC-F13UFX-H  
VPC-F13WFX  
VPC-F13WFX-B  
VPC-F13WFX-BC  
VPC-F13WFX-H  
VPC-F13X5E  
VPC-F13XFX  
VPC-F13XFX-B  
VPC-F13YFX  
VPC-F13YFX-B  
VPC-F13YFX-H  
VPC-F13Z0E  
VPC-F13Z0E-B  
VPC-F13Z1E-B  
VPC-F13Z1EBEE9  
VPC-F13Z8E  
VPC-F13Z8E-BI  
VPC-F13Z8R  
VPC-F13ZHJ  
VPC-F148FJ-B  
VPC-F149FJ-BI  
VPC-F14AFJ  
VPC-F14AGJ  
VPC-F14AHJ  
VPC-F14ZHJ  
VPC-F215FDBI  
VPC-F215FL  
VPC-F217HG  
VPC-F217HG-BI  
VPC-F219FC  
VPC-F219FC-BI  
VPC-F219FJ-BI  
VPC-F21AFJ  
VPC-F21AGJ  
VPC-F21AHJ

VPC-F21Z1E  
VPC-F21Z1E-BI  
VPC-F21Z1EBI  
VPC-F21Z1EBIEE9  
VPC-F21Z1EBIN  
VPC-F21Z1R  
VPC-F21Z1R-B  
VPC-F21ZHJ  
VPC-F221FX-B  
VPC-F221FX-S  
VPC-F223FX-B  
VPC-F224FDB  
VPC-F224FX-B  
VPC-F224FX-S  
VPC-F226FJ-S  
VPC-F226FM-B  
VPC-F227FJ-B  
VPC-F227FX-B  
VPC-F229FJ-BI  
VPC-F22AJ  
VPC-F22C5E  
VPC-F22E1R  
VPC-F22E1R-B  
VPC-F22FGX-B  
VPC-F22J1E  
VPC-F22J1E-B  
VPC-F22KFX-B  
VPC-F22L1E  
VPC-F22L1E-B  
VPC-F22L1EBEE9

VPC-F22L1EBEE96GB  
VPC-F22M0E  
VPC-F22M0E-B  
VPC-F22M1E  
VPC-F22M1E-B  
VPC-F22M1R  
VPC-F22M1R-B  
VPC-F22S1E  
VPC-F22S1E-B  
VPC-F22S1EB  
VPC-F22S1EBEE9  
VPC-F22S1R  
VPC-F22S1R-B  
VPC-F22S8E  
VPC-F22S8E-B  
VPC-F22SFX-W  
VPC-F232FX-B  
VPC-F233FX-B  
VPC-F234FX-B  
VPC-F235FDB  
VPC-F235FW



VPC-F235FW-B  
VPC-F236HG  
VPC-F236HW  
VPC-F236HW-B  
VPC-F237  
VPC-F237FJ-S  
VPC-F237FX  
VPC-F237FX-B  
VPC-F237HG  
VPC-F237HW  
VPC-F237HW-BI  
VPC-F238FJ-B  
VPC-F23A9E-B  
VPC-F23AJ  
VPC-F23CGX-B  
VPC-F23K1E  
VPC-F23L1E  
VPC-F23L1E-B  
VPC-F23L1EB  
VPC-F23M1E  
VPC-F23M1E-B  
VPC-F23M1EBEE9

VPC-F23M1EBEE98GB  
VPC-F23M1R  
VPC-F23M1R-B  
VPC-F23N1E  
VPC-F23N1E-B  
VPC-F23P1E  
VPC-F23P1E-B  
VPC-F23P1EB  
VPC-F23Q1E  
VPC-F23Q1E-B  
VPC-F23S1E  
VPC-F23S1E-B  
VPC-F23S1EBEE9  
VPC-F23S1R  
VPC-F23S1R-B  
VPC-F23X1R  
VPC-F23Z1E  
VPC-F23Z1E-B  
VPC-F23Z1R  
VPC-F244FDS  
VPC-F247FJ-S  
VPC-F248FJ-B  
VPC-F249FJ-BI  
VPC-F24AJ  
VPC-F24L1E  
VPC-F24L1E-B  
VPC-F24L1EB  
VPC-F24M1E  
VPC-F24M1E-B

VPC-F24M1EBEE9  
VPC-F24M1R  
VPC-F24M1R-B  
VPC-F24N1E  
VPC-F24N1E-B  
VPC-F24P1E  
VPC-F24P1E-B  
VPC-F24Q1E  
VPC-F24Q1E-B  
VPC-M11M1E-B  
VPC-M11M1E-W  
VPC-M120AL-L  
VPC-M120AL-P  
VPC-M121ADP  
VPC-M125AG-L  
VPC-M125AG-P  
VPC-M125AG-W  
VPC-M125AGP  
VPC-M126AA-L  
VPC-M126AA-P  
VPC-M126AA-W  
VPC-M126AG-L  
VPC-M126AG-P  
VPC-M126AG-W  
VPC-M126AH-L  
VPC-M126AH-P  
VPC-M126AH-W  
VPC-M129AJ-L  
VPC-M129AJ-P  
VPC-M129AJ-W  
VPC-M12M1E  
VPC-M12M1E-L  
VPC-M12M1E-P  
VPC-M12M1E-W  
VPC-M12M1EWEE9  
VPC-M12M1R-L  
VPC-M12M1R-P  
VPC-M12M1R-W  
VPC-M13M1E  
VPC-M13M1E-L  
VPC-M13M1E-P  
VPC-M13M1E-W  
VPC-M13M1EL  
VPC-M13M1ELEE9  
VPC-M13M1EP  
VPC-M13M1EPEE9  
VPC-M13M1EW  
VPC-M13M1EWEE9  
VPC-M13M1R-L  
VPC-M13M1R-P  
VPC-M13M1R-W  
VPC-S110FL  
VPC-S110FL-B

VPC-S110FL-P  
VPC-S111FM-S  
VPC-S113FG-B  
VPC-S113FGB  
VPC-S115EC  
VPC-S115FG  
VPC-S116FG  
VPC-S116FG-B  
VPC-S117GG  
VPC-S117GG-B  
VPC-S117GGB  
VPC-S118EC  
VPC-S119FJ  
VPC-S119FJ-B  
VPC-S119GC  
VPC-S11A7E  
VPC-S11A7E-B  
VPC-S11AFJ  
VPC-S11AGJ  
VPC-S11AHJ  
VPC-S11AVJ  
VPC-S11B7E  
VPC-S11C5E  
VPC-S11D7E  
VPC-S11D7E-B  
VPC-S11E7E  
VPC-S11F7E  
VPC-S11G7E  
VPC-S11H7E  
VPC-S11J7E  
VPC-S11J7E-B  
VPC-S11M1E  
VPC-S11M1E-W  
VPC-S11M9R-B  
VPC-S11V9E  
VPC-S11V9E-B  
VPC-S11V9R-B  
VPC-S11X9E  
VPC-S11X9E-B  
VPC-S11X9R-S  
VPC-S120FL  
VPC-S120FL-B  
VPC-S120FL-V  
VPC-S121GL  
VPC-S123FGB  
VPC-S125EC  
VPC-S128EC  
VPC-S129FJ-B  
VPC-S129FJ-S  
VPC-S129GC  
VPC-S12A7E  
VPC-S12A7E-B  
VPC-S12A7R

VPC-S12AFJ  
VPC-S12AGJ  
VPC-S12AHJ  
VPC-S12AVJ  
VPC-S12B7E  
VPC-S12C5E  
VPC-S12C7E  
VPC-S12C7E-B  
VPC-S12D7E  
VPC-S12E7E  
VPC-S12F7E  
VPC-S12J1E-W  
VPC-S12L9E-B  
VPC-S12M9E-B  
VPC-S12M9R-S  
VPC-S12V9E-B  
VPC-S12V9R-B  
VPC-S12X9E  
VPC-S12X9E-B  
VPC-S12X9EBEE9  
VPC-S12X9R-B  
VPC-S132FX-B  
VPC-S132FX-S  
VPC-S132GX-B  
VPC-S133GN  
VPC-S133GN-B  
VPC-S134GX-S  
VPC-S135EC  
VPC-S135EC-B  
VPC-S135EC-G  
VPC-S135EC-P  
VPC-S135FA-B  
VPC-S135FG-W  
VPC-S135FH-P  
VPC-S135FX-B  
VPC-S135FX-S  
VPC-S136EC  
VPC-S136EC-B  
VPC-S136EC-G  
VPC-S136EC-P  
VPC-S136FA-B  
VPC-S136FG-B  
VPC-S137GA-B  
VPC-S137GF  
VPC-S137GF-B  
VPC-S137GG  
VPC-S137GG-B  
VPC-S137GH-B  
VPC-S138EC  
VPC-S138EC-B  
VPC-S138EC-G  
VPC-S138EC-P  
VPC-S139FJ-B

VPC-S139FJ-P  
VPC-S139FJ-S  
VPC-S139GC  
VPC-S139GC-B  
VPC-S13A76  
VPC-S13A7E  
VPC-S13AFG  
VPC-S13AFG-B  
VPC-S13AFG-G  
VPC-S13AFG-P  
VPC-S13AFG-W  
VPC-S13AFH-B  
VPC-S13AFH-W  
VPC-S13AFJ  
VPC-S13AGJ  
VPC-S13AHJ  
VPC-S13B7E  
VPC-S13C5E  
VPC-S13CGX-B  
VPC-S13DGX-B  
VPC-S13EGX-B  
VPC-S13GGX-B  
VPC-S13I7E  
VPC-S13L8E  
VPC-S13L8E-B  
VPC-S13L9E-B  
VPC-S13L9EBEE9  
VPC-S13M1E  
VPC-S13M1E-W  
VPC-S13M1EW  
VPC-S13S8R  
VPC-S13S8R-S  
VPC-S13S9E-B  
VPC-S13S9R-S  
VPC-S13V9E-B  
VPC-S13X8E  
VPC-S13X8E-B  
VPC-S13X9E-B  
VPC-S13X9R-B  
VPC-S13Z9R-B  
VPC-S149FJ-B  
VPC-S149FJ-P  
VPC-S149FJ-S  
VPC-S14AFJ  
VPC-S14AGJ  
VPC-S14AHJ  
VPC-S14M  
VPC-Y110FL-B  
VPC-Y115FG-S  
VPC-Y115FGS  
VPC-Y115FX-B  
VPC-Y115FX-BI  
VPC-Y115FXBI

VPC-Y118EC  
VPC-Y118GX-BI  
VPC-Y119FJ  
VPC-Y119FJ-S  
VPC-Y11AFJ  
VPC-Y11AGJ  
VPC-Y11AHJ  
VPC-Y11AVJ  
VPC-Y11M1E  
VPC-Y11M1E-S  
VPC-Y11M1R-S  
VPC-Y11S1E  
VPC-Y11S1E-S  
VPC-Y11V9E  
VPC-Y11V9E-S  
VPC-Y216FX  
VPC-Y216FX-B  
VPC-Y216FX-G  
VPC-Y216FX-L  
VPC-Y216FX-P  
VPC-Y216FX-S  
VPC-Y216FX-V  
VPC-Y216GX  
VPC-Y216GX-B  
VPC-Y216GX-G  
VPC-Y216GX-L  
VPC-Y216GX-P  
VPC-Y216GX-S  
VPC-Y216GX-V  
VPC-Y218EC-BI  
VPC-Y218EC-G  
VPC-Y218EC-L  
VPC-Y218EC-P  
VPC-Y218EC-R  
VPC-Y219FJ-S  
VPC-Y21A7E  
VPC-Y21AFJ  
VPC-Y21AFX-B  
VPC-Y21AGJ  
VPC-Y21AHJ  
VPC-Y21AVJ  
VPC-Y21B7E  
VPC-Y21BGX-B  
VPC-Y21C5E  
VPC-Y21EFX-B  
VPC-Y21EFX-V  
VPC-Y21M1R-G  
VPC-Y21M1R-L  
VPC-Y21M1R-P  
VPC-Y21M1R-V  
VPC-Y21S1E-G  
VPC-Y21S1E-L  
VPC-Y21S1E-P

VPC-Y21S1E-S  
VPC-Y21S1E-SI  
VPC-Y21S1ESIEE9  
VPC-Y21SFX-R  
VPC-Y21V9E-B  
VPC-Y22C5E  
VPC-Y22Z5008B  
VPC-Y22Z5009Q  
VPC-Y22Z5010B  
VPC-YA15EC  
VPC-YA15EC-B  
VPC-YA15EC-R  
VPC-YA15FG  
VPC-YA15FG-B  
VPC-YA15FG-R  
VPC-YA15FH-B  
VPC-YA15FH-R  
VPC-YA16EC  
VPC-YA16EC-B  
VPC-YA16EC-R  
VPC-YA16FW  
VPC-YA17GG  
VPC-YA17GG-B  
VPC-YA17GG-R  
VPC-YA17GH-B  
VPC-YA17GH-R  
VPC-YA17GW  
VPC-YA19FJ-B  
VPC-YA1C5E  
VPC-YA1V9E  
VPC-YA1V9E-B  
VPC-YA1V9R  
VPC-YA1V9R-B  
VPC-YA25EC  
VPC-YA26EC  
VPC-YA2AJ  
VPC-YB10AL-P  
VPC-YB10AL-S  
VPC-YB13KDS  
VPC-YB13KX  
VPC-YB13KX-G  
VPC-YB13KX-P  
VPC-YB13KX-S  
VPC-YB14KX  
VPC-YB14KX-G  
VPC-YB14KX-P  
VPC-YB14KX-S  
VPC-YB15AG  
VPC-YB15AG-G  
VPC-YB15AG-P  
VPC-YB15AG-S  
VPC-YB15AH-G  
VPC-YB15AH-P

VPC-YB15AH-S  
VPC-YB15AL  
VPC-YB15AL-P  
VPC-YB15AL-S  
VPC-YB15JC  
VPC-YB15KX  
VPC-YB15KX-G  
VPC-YB15KX-P  
VPC-YB15KX-S  
VPC-YB15KXP  
VPC-YB16KG-G  
VPC-YB16KG-P  
VPC-YB16KG-S  
VPC-YB19KJ-G  
VPC-YB19KJ-P  
VPC-YB19KJ-S  
VPC-YB1S1E  
VPC-YB1S1E-S  
VPC-YB1S1ESASIS  
VPC-YB1S1ESEE9  
VPC-YB1S1R  
VPC-YB1S1R-S  
VPC-YB20AL  
VPC-YB20AL-B  
VPC-YB20AL-P  
VPC-YB29KJ-G  
VPC-YB29KJ-P  
VPC-YB29KJ-S  
VPC-YB2L1R  
VPC-YB2L1R-B  
VPC-YB2L1R-G  
VPC-YB2L1R-P  
VPC-YB2L1R-S  
VPC-YB2M1E  
VPC-YB2M1E-G  
VPC-YB2M1E-P  
VPC-YB2M1E-S  
VPC-YB2M1EGEE9  
VPC-YB2M1EP  
VPC-YB2M1EPEE9  
VPC-YB2M1ES  
VPC-YB2M1ESEE9  
VPC-YB33KDB  
VPC-YB33KX-B  
VPC-YB33KX-P  
VPC-YB33KX-S  
VPC-YB35AL  
VPC-YB35AL-S  
VPC-YB35AN-B  
VPC-YB35JC  
VPC-YB35KX  
VPC-YB35KX-B  
VPC-YB35KX-P




VPC-YB35KX-S  
VPC-YB35KXS  
VPC-YB36KG  
VPC-YB36KGP  
VPC-YB36KW  
VPC-YB36KW-P  
VPC-YB36KW-S  
VPC-YB3Q1R  
VPC-YB3Q1R-B  
VPC-YB3Q1R-G  
VPC-YB3Q1R-P  
VPC-YB3Q1R-S  
VPC-YB3V1E  
VPC-YB3V1E-G  
VPC-YB3V1E-P  
VPC-YB3V1E-S  
VPC-YB3V1EGEE9  
VPC-YB3V1EP  
VPC-YB3V1EPEE9  
VPC-YB3V1ESEE9  
VPC-YB45JB  
VPC-YB45JB-B  
VPC-YB45JB-P

Â



## IMBALLAGGIO SICURO

in busta elettrostatica con protezioni antiurto



## ATTENZIONE: ricorda di conservare l'imballo originale

Solo così potrai avvalerti della garanzia e del diritto di recesso

In conformità alla normativa italiana in materia di restituzioni, non si accetteranno in nessuna circostanza resi privi della confezione integra in tutte le sue parti.



### ISTRUZIONI

### PER L'USO



**NON SCARICARE LA CARICA RESIDUA**  
appena acquistata metti subito in carica la batteria



**FAI 3 CICLI DI CARICA DA 8 ORE**  
servirà alla batteria per attivarsi chimicamente



**STACCA L'ALIMENTATORE QUANDO SEI AL 100%**  
dal 4° ciclo stacca sempre dall'rete la batteria appena  
per caricarla non scaricandola mai completamente alla 0%

[Informazioni Venditore](#)

**Recensioni Clienti:** Nessuna recensione disponibile per questo prodotto.  
Autenticati per poter scrivere una recensione.